

SUP RACK

Model # 11-0701

Model # 12-0105



PARTS LIST	
Qty	Name
2	SUP Rack with Strap
4	Phillips Head Screw

Holds up to 125 LBS



STEP 1

There are 3 ways to mount the rack:

- Wall
- Free-Standing Frame Direct
- Free-Standing Frame with Brackets

A. Mounting to Wall

Tools Needed : Tape Measure, Electric Drill, $\frac{3}{16}$ " Drill Bit, #3 Phillips Head Driver, and a cold beverage of your choice

The length of your SUP will determine arm spacing. Ideal arm spacing is 40% of total boat length, (boat length X 0.4 = spacing).

1. Locate studs where arms will be mounted and mark desired height for the arms. Push a mounting screw into wall to mark the locations for holes. Wall studs are typically on 16" centers. *Screwing only into drywall is not sufficient and could result in injury to self and SUP.*
2. Pre-drill pilot hole for Phillips Head screw using a $\frac{3}{16}$ " drill bit.



Pro Tip: An old woodworkers trick is to rub the screw threads on a bar of soap for easy installation.

3. Use the #3 Phillips Head Driver to insert top screw. Initially, leave top screw loose (helps when locating hole for lower screw). Use offset screwdriver to insert bottom screw. After inserting bottom screw, tighten both screws.
4. Mount second arm at same height as first arm.



If you have not yet opened your cold beverage, this would be an appropriate time to do so.


Rev. 04/19

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM



B. Free-Standing Frame: Direct


Tools Needed : Two ½" Wrenches *or* one ½" Wrench and one #5 Allen Wrench

Using mounting hardware supplied in frame box, insert bolts through holes in arms then into the frame and tighten securely.

Go to **STEP 2**

STEP 2: Strap Adjustments

1. Detach safety strap (top strap) from Velcro on support strap (bottom strap). Set length of support strap so SUP will be suspended without touching the steel frame.
2. Reattach safety strap to support strap.
3. Once loaded onto arms, place safety strap over SUP or Board. Buckle ends together, then adjust length of safety strap to achieve a snug fit.



C. Free-Standing Frame: with Brackets

Tool Needed : ½" Wrench


Attach Free-Standing bracket using instructions provided with the bracket. Attach arms to the frame using the locking pin. The locking pin can be inserted in either top or bottom hole of bracket for more exact positioning.

Note: Brackets sold separately: Model #31-5501 (Yellow) or Model # 31-5502 (Black).

Brackets are required for attaching arms to back side of frame.

Go to **STEP 2**

Make it a Double!



To make a Double SUP Rack, use the SUP Expansion Plates (Model# 31-5503/31-5504 Marine Grade) and a second set of SUP Racks.

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

OUR PLEDGE TO YOU

SuspENZ® products are warranted for life against defects in material or workmanship to the original owner. Product must be used for its intended purpose under normal conditions. Please visit www.SuspENZ.com for complete warranty information.

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM