



PARTS LIST	
Qty	Name
1	Stow & Go Strap
2	Mounting Bracket
4	Phillips Head Screw
1	Mesh Storage Bag

Holds up to 75 LBS



Mounting Instructions

Tools Needed : Tape Measure, Electric Drill, $\frac{3}{16}$ " Drill Bit, and #3 Phillips Head Driver

1. Locate the wall studs where Stow & Go System will be mounted. The recommended spacing is 16" apart for typical stud spacing.
2. Use a Mounting Bracket as a template to mark the hole locations. Push a mounting screw into wall to mark the locations for holes.



Pro Tip: An old woodworkers trick is to rub the screw threads on a bar of soap for easy installation.

3. Use the $\frac{3}{16}$ " drill bit to drill both holes. It is important that these go into a wood stud.
4. Use #3 Phillips Head Driver to insert screws through bracket and into holes. Repeat for second bracket.
5. Adjust the strap lengths to you and your SUP, kayak or surfboard.

Transport Instructions

When using for SUP or kayak transport, the Stow & Go System may be carried on one shoulder or across the body, messenger bag style. Simply adjust the straps for a comfortable fit and to ensure that your SUP, kayak or board has plenty of clearance from the ground.