





<b>Fixture Installation Instructions</b>	<b>Product: G16 – G24 Series DF Globes</b>
<b>Effective Date:</b> September 20, 2021	<b>Part Description:</b> VCOB Retrofit Kit

	<b>WARNING:</b> To avoid fire, shock or death, turn off and lockout power before performing any maintenance.
	<b>CAUTION:</b> This Fixture must be wired in accordance with the National Electric Code (NEC) and all applicable local codes. Proper grounding is required. All work should be done by a qualified electrician.

<b>A. Remove Roof of Fixture</b>	
	<b>Step 1:</b> Unpack VCOB conversion kit. Handle with care, being careful not to touch the optics. Recycle the empty packaging.
	<b>Step 2:</b> Loosen the set screws holding the globe in place. Lift globe off fitter and set aside for later use.




**Step 3:** Unlatch the two latches on the fitter cover and lift it out of the fitter. Disconnect the supply wiring from the ballast. These components will not be needed for the retrofit. Please dispose of the cover and ballast assembly properly.



**Step 4:** Connect the VCOB retrofit kit to the supply lines. With the "STREET" designation on the fitter cover on the street side of the fixture, place the cover on the fitter taking care not to pinch any wires between the cap and the fitter. Latch the cover in place. Replace globe and tighten set screws uniformly.



**Wiring Diagram**



Revision History				
Rev	Description of Revision	ECN Number	Design Engineer Author	Engineering Approval
A	Initial Release	ECN 09-20-2021 RAY	RAY	MR