

# 12 DIGITS SPORTWATCH INFORMATION

## FEATURES

- 12digits display with light
- Alarm with 4 min. snooze
- 12/24-hour format
- Chime for every hour
- Chronograph with 1/100 th
- Second lap operation
- EL backlight

## FEATURE SELECTION

Normal Display: Month, Date, Day Of Week, Hour, Minute

Press button A: 3 second back light

Press button B: stopwatch start/stop.

Press button C: once: enter "Stopwatch mode"

Press button C: twice: enter "Alarm set mode".

Press button C: three times: enter "Time set mode" (seconds will flash).

Press button C: four times: shows normal display.

Press button D: reset stopwatch



## TO SET TIME/CALENDAR

1. From normal display, press C three times, "seconds" display will change to time set mode. "seconds" digits will flash.
2. Press B: to set seconds to "00".
3. Press D: "Hour" digits will flash, press B to set hour. Hour will run from 12 hours to 24 hours
4. Press D: "Minute" digits will flash, press B to set minute.
5. Press D: "Month" digits will flash, press B to set month.
6. Press D: "Date" will flash, press B to set date.
7. Press D: "week" will flash, press B to set week.
8. Press D: return to normal display.

## TO SET DAILY ALARM

1. From normal display, press C twice, display will change to alarm set mode(Alarm will be on display)
2. Press D: "Hour" digits will flash, press B to set hour.
3. Press D: "Minute" digits will flash, press B to set minute.
4. Press D: return to alarm set mode, digit will not flash.
5. Press B: daily alarm will be turned on
6. Press B again: hourly alarm will be turned on
7. Press B again: daily & hourly alarms will be turned on
8. Press B again: alarm will be turned off
9. Press C: return to normal display.

## STOPWATCH-EVENT AND TIME-OUT TIMING

1. From normal display, press C once to enter stopwatch mode.
2. Press B to start stopwatch.
3. Press B again to stop stopwatch.
4. Press D to reset stopwatch to "00".
5. Press C once to return to normal time.

## STOPWATCH-CUMULATIVE SPLIT TIMING

1. From stopwatch mode press B to start stopwatch
2. Press D to display cumulative split time(stopwatch will Continue to count internally).
3. Press D to release split time and display overall elapsed time in progress. This may be repeated as many times as necessary .
4. Press B to stop counting. Press D to reset stopwatch to "00"

## ONE-TWO FAST FINISH-TIMING TWO RACERS

1. From stopwatch mode press B to start stopwatch
2. Press D when the first racer crosses the finish line.
3. Press B when the second racer crosses the finish line. Record the time on the display, then press D to get the second racer's time. Record the time.
4. Press D to reset the stopwatch to "00"

## BATTERY REPLACEMENT

When the readout becomes dim, it is time to replace the CR2016 Lithium battery.