

Product information

Product Name: Core Direct qRT-PCR SYBR Kit

Catalog No: VND790RSK, VND791RSK

Packing Size: 500 x 25 ul rxns and 250 x 25 ul rxns

Shipping Condition: Ice pack / dry ice

Storage Condition: -20°C **Product Description:**

The Core Direct qRT-PCR SYBR Kit is designed for real-time quantitative analysis of target RNA directly from blood, serum/plasma, swabs, cell cultures, bacterial colonies, and animal or plant tissue. The kit enables robust amplification without requiring prior RNA purification procedures.

The kit is optimized with our unique inhibitor-resistant, thermostable polymerases and buffer system for optimal performance. In most cases, samples can be added directly to

the RT-PCR master mix without the need for pre-lysis.

The blend of polymerases is packaged separately from the 2X RT-PCR Mix, allowing scientists to optimize the enzyme amount for their specific application based on the

inhibitory level in the samples. The kit ensures fast and easy preparation with a minimum of pipetting steps and is especially recommended for:

- Direct detection of viral or bacterial RNA in nasal or throat swabs
- Direct qRT-PCR from blood samples and other body fluid
- Direct qRT-PCR from cell culture
- Direct quantitative analysis of target RNA from single colonies or cells
- Direct amplification of target RNA from various tissue samples

Please note that this kit does not contain a Passive Reference Dye ROX. If your instrument requires a reference dye, you may add ROX to the reactions. Please refer to the following table for more details.

Final concentration of ROX dye in PCR	Recommended Cyclers
	ABI® PRISM
500 nM	7000,7300,7700,7900HT, 7900Fast, StepOnePlus™, StepOne™
	ABI® PRISM
50 nM	7500, 7500Fast
	-Stratagene® Mx3000, Mx3005P, Mx4000
	BioRad® iCycler®, iQ ™5, MyiQ™
No	BioRad® CFX96
	Roche LightCycler® 480
	MJ Research Opticon™ And Opticon™ 2,
	MJ Research Chromo® 4
	Corbett Rotor-gene® 6000, 3000
	DNA Engine Option [®] 2 and Chromo 4 [™]
	Eppendorf® Realplex

List of Components:

- Direct gRT-PCR Pols: 2x 250 ul (500 rxns) and 1 x 250 ul (250 rxns)
- 2X Direct qRT-PCR SYBR Mix: 5 x 1.25 ml (500 rxns) and 3 x 1.05 ml (250 rxns)
- Lysis Buffer-B: 1 x 100 ml (500 rxns) and 1 x 50 ml (250 rxns). Please handle with care and wear personal protective equipment!

Protocol:

First Option: Directly add samples into PCR mix. Please always perform this option first.

- For blood, serum, plasma, or other body fluid samples: Add 1.0 μ l of the sample directly into a 25 μ l RT-PCR mix.
- For cell culture: Add 1.0 µl of the cell culture directly into the RT-PCR mix. Alternatively, wash the cell culture with PBS, suspend it in PBS, and add 1.0 µl into a 25
- For colony screening: Pick a single colony with a pipette tip and add it into a 25 µl RT-PCR mix.

 For nasal/throat swab samples: Transfer 100-200 µl of lysis buffer into a 1.5 ml microtube. Cut off the cotton tip with the collected nasal or throat swab and place it in the microtube. Close the tube and vortex for 15 seconds. Incubate at room temperature (20-25 °C) for 2-3 minutes. Remove the cotton tip and squeeze it out at the rim of the tube. Centrifuge briefly and transfer 1-2.5 µl of the supernatant into a 25 µl PCR mix.
- For animal tissue and plant samples: Use second option

Second Option: Lyse the samples prior to adding them into PCR

Blood Samples / Liquid Samples

- Transfer 5 µl-10 µl of the blood / serum / plasma / other liquid sample into a tube containing 50-100 µl Lysis Buffer (a dilution ratio 1:10 to 1:20 in Lysis Buffer is recommended)
- Close the tube and vortex for 15 sec
- Incubate the tube at 95° C for 2-3 min, then 4° C for 5 min or on ice
- Centrifuge at 12,000 rpm for 2-5 min
- Transfer 1-2.5 µl of the supernatant into a 25 µl PCR assay or 2-5 µl into a 50 µl RT-PCR assay

Samples from cell culture

- Collect cells and wash with PBS
- Suspend the cells in a tube with 50-100 µl Lysis Buffer
- Incubate the tube at 95° C for 2-3 min, then 4° C for 5 min or on ice
- Centrifuge at 12,000 rpm for 2-5 min
- Transfer 1-2.5 µl of the supernatant into a 25 µl RT-PCR assay or 2-5 µl into a 50 µl RT-PCR assay

Samples from colonies

- Transfer 5-10 µl Lysis Buffer into a 0.2 ml microtube
- Pick a single colony and add into RT-PCR mix
- Incubate the tube at 95°C for 3 min, then 4°C for 5 min or on ice
- Transfer 1-2.5 μ l of the supernatant into a 25 μ l RT-PCR assay or 2-5 μ l into a 50 μ l RT-PCR assay

Samples from nasal or throat swabs

- Transfer 200 µl Lysis Buffer into a 1.5 ml microtube
- Cut off the cotton tip with the collected nasal or throat swab and place it in the micro tube
- Close the tube and vortex for 15 sec
- Incubate the tube at 95°C for 2-3 min, then 4°C for 5 min or on ice
- Remove the cotton tip and squeeze it out at the rim of the tube Centrifuge briefly and transfer 1-2.5 μ l of the supernatant into a 25 μ l PCR assay or 2-5 μ l into a 50 μ l PCR assay

Samples from Animal or Plant Tissue

- Prepare a small piece (1-4 mm diameter) from animal or plant tissue
- Crack plant seeds to less than 1 mm in diameter using a BeadBeater, Tissue Lyser or small hammer
- Place the sample in a microtube containing 50-100 μ I Lysis Buffer Incubate the tube at 95 $^{\circ}$ C for 2-3 min, then 4 $^{\circ}$ C for 5 min or on ice
- Centrifuge at 12,000 rpm for 2 min
- Transfer 1-2.5 µl of the supernatant into a 25 µl RT-PCR assay or 2-5 µl into a 50 µl RT-PCR assay

Table 1. PCR setting for a 25 µl reaction

Reagent	Volume	Final Concentration
De-ionized Distilled H ₂ O	Adjust final volume to 25 μl	
2X Direct qRT-PCR Mix	12.5 µl	1X
Direct qRT-PCR Pols [†]	1.0 µl	
Left Primer	Variable	0.2-0.5 μM
Right Primer	Variable	0.2-0.5 μM
ROX (not included)	Variable (refer to the table above)	0-500 nM
Crude Sample*	1.0 µl (blood/serum/plasma/other body fluid/cells suspension/nasal or throat suspension) Single colony (from plate)	
Crude Extract*	1-2.5 µl / 25 µl or 2-5 µl / 50 µl	4-10%

[†]We strongly recommend conducting an enzyme titration experiment by testing enzyme concentrations ranging from 0.5 to 1.0 μl per 25 μl reaction to determine the optimal enzyme concentration for your specific target.

Please centrifuge the samples at 12,000 rpm for 2-5 minutes to pellet debris if you are using the first option. Then, load 5-10 µl of the supernatant onto a gel to visualize the amplification product.

Table 2. Typical Cycling Parameters

A. Three steps

A: Thice stops.				
RT	55-60°C	20-30 min		
Then denaturation	95°C	5-10 min		
Then followed by 35-45 cycles				
Denaturation	94°C	20 to 30 sec		
Annealing	50°C to 68°C	30 to 60 sec		
Extension	70°C	2 min / kb		

B. Two steps

B. Two steps.		
RT	55-60 ⁰ C	20-30 min
Initial denaturation	95°C	5-10 min
Then followed by 35-45 cycles		
Denaturation	94°C	20 to 30 sec
Annealing / Extension	60-65°C	2 min / kb

Note: The cycling conditions provided above serve as a guideline. We strongly recommend conducting gradient annealing temperature experiments to determine the optimal conditions for your specific targets. If you are performing multiplex RT-PCR, it is crucial to carefully design the primers and have prior knowledge of the optimal cycling conditions. We suggest conducting the RT step at 55-60°C for 20-30 minutes. You may use your own cycling conditions for the subsequent steps if you know the optimal conditions for your target. If you employ a lysis procedure, you may use a lower temperature for the RT step.

Troubleshooting guide

No signal	Please check your PCR settings to ensure that all necessary components are included in the PCR mix. It's also recommended to perform a gradient annealing temperature experiment to determine the optimal temperature for your specific target. This can help to improve PCR efficiency and specificity, resulting in more reliable and consistent results.
Low signal	If you are using the first option, it's important to set RT step at 55-60°C for 20-30 minutes to ensure proper release of RNA. Additionally, you can try the following strategies to improve PCR performance:
Unexpected variation	If you are experiencing unexpected variations in your real-time PCR results, there are a few steps you can take to address the issue. First, check your pipette to ensure that it is calibrated and accurate. Additionally, you should verify whether you need to add a ROX reference dye that is suitable for your specific PCR cycler model (please refer to the manufacturer's instructions or the provided reference table).

This product is for R&D use only

^{*}Please ensure that you assemble all components and distribute the master mix into each PCR tube/well before adding crude samples to the bottom of the tubes/wells. Also, avoid disturbing the bottom of the tube/well when adding samples.