

Indoor Media Display KOM CYCLING









Steps






The four mounting holes farthest away from the water bottles. This will situate the desktop in the most forward position giving you the easiest access to grab or interact with the items on the desktop. This mounting option is recommended when using the desktop with a laptop computer.



The four mounting holes closest to the front of the desktop (near the water bottle wells). This mounting option is recommended when using the desktop with a tablet in the forward mounting slot.




Install the T-bracket to the chosen location, Line up the 4 holes in the T-bracket with the threaded holes in the desktop. Insert the M6 bolts through the hole in the T-bracket and thread the bolt into the desktop. Tighten bolts to secure the T-bracket to the desktop.

Unpack the tripod base and loosen the bottom knob 1-2 full turns. Extend the legs of the tripod by pulling on the legs and sliding the collar along the tripod center rod. Tighten the bottom knob when legs are in extended position.

Indoor Media Display







For easy transport or storage, the desktop with T-bracket can be detached from the tripod base and the tripod legs collapsed.