







PARTS LIST

ATTENTION: Before you begin to assemble the product, please make sure that all the parts are included in the package, and inspect them for damages or defects.




ATTENTION:

- To avoid misalignments, leave the screws loose and do not tighten them until all are in place.
- Do not overtighten or force the screws as they could break or strip.
- Using the wrong size of screws on a part might cause damage to it.


STEP 1

Insert all the casters (F) into the base (C) using pressure, then place the gas lift (E) in the middle of the base.




STEP 2

Assemble the back (A) to the seat (B) using screws (G) as shown.



STEP 3

Place the mechanism (D) over the metal support of the back (A), making sure the holes align with the holes on the seat (B), and assemble it using screws (G) as shown.





STEP 4

Place the top parts of the chair over the base parts making sure the gas lift enters into the center hole of the mechanism.

Before using the chair for the first time, make sure that all the screws are tightened.

The top and base parts will stay together by pressure after seating.





LIFT FUNCTION:

- To raise or lower the chair's height: Pull the lever UP with force. The chair will go down while sitting on it, or up if you lift your body.

WARNINGS:

- Do not stand up on the chair.
- Do not use the chair as a ladder.
- Use for seating only one person at a time.
- At least every 4 months, check all bolts, screws and knobs to be sure they are tight. Do not use if parts are loose, damaged or missing.
- Failure to follow the above warnings could result in serious injury.
- Do not apply solvents or polishers directly to the chair parts to clean them. Instead, use a soft damp towel with a solution of mild soap and water.