



## Flex-a-Bowl Scale™

BSCFB2000

Customer Service  
(North America):  
**1-888-538-8683**  
Local  
(Wyoming, USA):  
**307-222-6086**  
Email:  
[help@mybrewista.com](mailto:help@mybrewista.com)



**READ THIS MANUAL PRIOR TO FIRST USE AND SAVE FOR FUTURE REFERENCE**  
1-year Limited Warranty

Thank you for purchasing our digital scale (BSCFB2000). With normal care and proper treatment, this scale will provide years of reliable service.

### Components

- 1 Flexible Bowl / Protective Cover
- 2 Platform
- 3 ON/OFF button
- 4 Measuring Units
- 5 LCD Readout
- 6 Weight
- 7 MODE button



Fig. A: Illustration of the Scale's Components and Controls

### General Maintenance and Care

- Avoid exposure to extreme heat or cold.
  - Always allow your scale to acclimate to normal room temperature before use.
- Keep your scale in a clean environment.
  - Excessive dust, dirt, vibration, air currents, as well as close proximity to other electronic equipment may have an adverse effect on the accuracy and reliability of the scale.
- Handle the scale with care.
  - Set all items to be weighed gently on the top of the platform.
  - Although this scale is designed to be quite durable, avoid rough treatment as this may permanently damage the internal components.
  - Always avoid violent shaking and dropping.
  - This is a precision instrument and should be handled as such.

### Battery Installation

The scale includes two (2) AAA batteries. The batteries will need to be installed prior to use.

- 1 Remove the plastic wrap from the batteries and discard.
- 2 Remove the battery cover from the base.
- 3 Slide the negative end of the battery into place against the spring. Press the positive end of the battery down until the battery slides into place.
- 4 Repeat with the second battery.
- 5 Replace the battery cover.

*Please note:* If your scale reads “LO” on the display or will not power on, replace the batteries by following these steps.

### Specifications and Functions

- Capacity: 2000g
- Accuracy: 0.1g
- Measuring Units: Grams (g), Ounces (oz), Troy Ounces (ozt), Pennyweight (dwt)
- Button functions: ON/OFF & TARE, MODE
- Display: LCD with backlight
- Auto-off
  - Auto-off function is set to 180 seconds by default.
  - Auto-off can be set to 60 seconds, 120 seconds, 180 seconds, or disabled manually.
- Power: (2) AAA batteries (included)
- Operation temperature range: 50° to 85° Fahrenheit (10° to 30° Celsius)

### Flexible Bowl / Protective Cover

The protective cover expands to become a bowl OR the bowl collapses to become a protective cover, depending on its current state.

- To expand the protective cover and convert it to a bowl:
  - Grip the outer orange rim.
  - Push the flat orange bottom from the inside outward.
- To collapse the bowl and convert it to a protective cover:
  - Place the bowl upright on a flat surface.
  - Push downward on the outer orange rim.

### Operation

- 1 Place the scale on a level surface & press ON/OFF button to turn on the scale.
- 2 When the LCD display shows zero, press MODE button to choose the weighing unit.
- 3 Place the item to be weighed on the platform and wait until the reading is stable.

*Please note:* When removing weight from scale, do not apply downward force to the platform. Doing so may result in inaccurate readings.

## Tare Function

- 1 Turn on the scale as described above.
- 2 Place the item to be tared (i.e. the bowl) on the platform.
- 3 Press ON/OFF button and wait until the LCD displays zero.
- 4 Scale can now be used for weighing.
- 5 Add the item to be weighed (i.e. coffee beans).
- 6 The weight is displayed on the LCD.

## Auto-off Function

- The Auto-off function is set to 180 seconds by default.
- Auto-off can be set to 60 seconds, 120 seconds, 180 seconds, or disabled manually.
- To change the Auto-off time setting or disable this function:
  - 1 Turn off the scale.
  - 2 Press and hold the ON/OFF and MODE buttons at the same time until "180" is displayed.

## Calibration

**⚠ This scale is factory calibrated and does not require calibration before use. Only calibrate your scale if you are experiencing drifts in your measurements. When calibrating your scale it is mandatory to use the correct calibration weights. If you do not use the correct weights, all readings thereafter will be incorrect. If you accidentally put the scale in calibration mode simply turn the scale off to exit.**

- 1 When the scale is off, press ON/OFF button to turn on the scale.
  - The LCD will read "0.0g".
- 2 Press and hold the MODE button until the display shows "CAL", then release the button.
- 3 Press MODE button again.
  - "2000g" will flash on the display.
- 4 Place a 2000g calibration weight onto the center of the platform.
- 5 The LCD will read "PASS" then "2000g".
- 6 Calibration is complete.

## Washing Instructions

This scale has been treated with a liquid repelling Nano-coating which allows you to wash your scale without damaging the internal electronics. Please follow these instructions when washing:

- 1 Hand wash only with mild soapy water.
  - 2 Wash only the platform. Rinse other parts with clean water if needed.
  - 3 After washing the scale, shake out excess water. It is best to do this by firmly grasping the scale in one hand, being careful not to press hard on the platform. Then tap it against your other hand to allow the water to drip out of the scale.
  - 4 Dry the exterior of the scale with a soft cloth or leave to dry on a dish rack.
- ⚠ **DO NOT use liquid bleach or other harsh chemicals.**
  - ⚠ **DO NOT use steel wool or abrasive sponges as this can scratch the surface.**
  - ⚠ **DO NOT submerge the scale.**

- 3 Release both buttons.
- 4 Press the MODE button to change from 60, 120 or 180 seconds.
  - If "0" is selected, the Auto-off function will be disabled.
- 5 After choosing the desired time, press the ON/OFF button again to confirm the new setting

### Note:

- If "60", "120", or "180" is chosen, the scale will turn off after the designated number of seconds of inactivity.
- If the Auto-off function is disabled, the scale will not shut off on its own.

*Please Note:* To maintain a longer battery life, please turn off the scale by pressing the ON/OFF button after each use.

## Warning Messages

- "LO": Low voltage
  - Replace the batteries.
- "EEEE": Overload
  - Quickly remove weight from platform to protect the scale.
- "UNST":
  - Scale is not steady during start up. Please turn off scale, set on a stable surface and restart scale.
  - Water is inside the scale. Shake out excess water and let dry.

**⚠ Avoid pouring water directly into your scale, as water may become trapped. If this occurs drying time may exceed 4 hours.**

**⚠ Water drops on the LCD display will not interfere with your weighing. These drops will dry and disappear.**

**⚠ If the scale displays "UNST" or the readings jump after washing, then water is still inside the scale. Simply shake out the excess water and let your scale dry longer.**

**⚠ Batteries should not come in contact with water. The battery compartment has a silicone seal to prevent this. In the event that you wash the scale with the battery compartment open, please dry out the battery compartment with a soft cloth and make sure the batteries are dry before re-installing the batteries.**

**⚠ If you open the compartment and lose the silicone seal you may replace the seal with an included spare seal. The silicone seals are white in color. Two (2) spare seals are included.**

By following these washing instructions, you will experience shorter drying times and your scale will provide you with years of reliable service.