



## Allbäck Linseed Oil Putty Estimating Guide

USE FOR GLAZING WINDOWS & USE AS A FILLER


Sage Restoration Inc.  
3 Mill Pond Drive  
Tamworth, ON K0K 3G0

PRODUCT NAME Allbäck Linseed Oil Putty  
BINDER Cleaned and matured raw linseed oil  
THINNER Cleaned raw linseed oil

---

### DEFINITIONS

- S** = Number of **Sash**.
- L** = Number of **Lights** per sash.
- W** = **Width** of rebate in inches.
- D** = **Depth** of rebate in inches.
- P** = **Perimeter** of each light of glass in inches.



*Cross section of muntin showing  
glass rebate Width and Depth.*

---

### PUTTY ESTIMATING FORMULA

$$S \times L \times W \times D \times P \times 0.0167 = \text{Kg of putty needed}$$

---

### EXAMPLE

If your window glazing job consists of 24 6-light sash with a 5/16" wide by 3/8" deep glass rebate and a 6" x 8" glass size:

$$24(S) \times 6(L) \times 0.3125(W) \times 0.375(D) \times 28(P) \times 0.0167 = 7.89 \text{ Kg Putty needed}$$

---

### MORE INFO

This guide is for estimating purposes only. Actual quantity of putty required may vary depending on project conditions and method of application.

Consult the [Little Handbook About Allbäck Linseed Oil Paint](#) for more information and application tips. Pages 17 and 18 discuss putty in particular.

Consult the [SDS for Allbäck Linseed Oil Putty](#).

**Contact:** Sage Restoration Inc. | [sagerestoration.com](http://sagerestoration.com) | 1 866 516 7787 | [info@sagerestoration.com](mailto:info@sagerestoration.com)