

RevNo	Revision note	Date	Signature	Checked
1	REVISED TEXT	5/15/2020	LCASAREZ	HVG
2	REVISED TEXT	6/2/2020	LCASAREZ	HVG
3	UPDATED PART NUMBER	9/3/2020	LCASAREZ	HVG

GEAR LOFT INSTALLATION INSTRUCTIONS

GENERAL DESCRIPTION

1. VERIFY ALL COMPONENTS ARE INCLUDED USING THE EXPLODED DIAGRAM PROVIDED.
2. THERE ARE 3 MOUNTING POINTS ON EACH SIDE OF THE LOFT.
 - 2.1. THE STRAP MOUNT (ITEM #4) WILL BE SANDWICHED IN BETWEEN THE VISOR SHELF AND HEAD LINER.
 - 2.2. THE FRONT SUPPORT (ITEM #2) WILL MOUNT ABOVE THE HAND RAIL USING NEW HARDWARE INTO AN EXISTING MOUNTING POINT.
 - 2.3. THE REAR SUPPORT (ITEM #3) WILL MOUNT IN PLACE OF THE FACTORY GARMENT HOOK AND WILL USE THE EXISTING HARDWARE.
3. THE TUBING WILL SLIDE THROUGH THE REAR MOUNT (ITEM #3) AS WELL AS THE FRONT MOUNT (ITEM #2) AND BE JOINED AT THE CENTER WITH THE COUPLER (ITEM #1).
4. THE PRESTA CYCLE TORQ-KEY IS A COMPLIMENTARY GIFT AND WILL ALLOW YOU TO TIGHTEN THIS COUPLER TO THE CORRECT TORQUE SPEC WITHOUT THE WORRY OF OVER-TIGHTENING AND BREAKING SCREWS.
5. THE LOFT PLATFORM (ITEM #8) WILL BE INSTALLED ONTO THE TUBING ONCE IT'S IN PLACE.


DETAIL INSTRUCTIONS

INSTALLING THE MOUNTS AND TUBING

1. REMOVE THE CENTER VISOR SCREWS ON EACH SIDE. FROM ABOVE THE VISOR (SHELF SPACE) INSTALL THE STRAP MOUNT (ITEM #4) BETWEEN THE VISOR AND HEADLINER WHILE POSITIONING THE SLOT TOWARDS THE REAR. REINSTALL ORIGINAL SCREW, AND TIGHTEN. USE CAUTION WHILE TIGHTENING HERE; DO NOT OVER-TIGHTEN.
2. REMOVE THE FRONT SCREW FOR THE FACTORY HANDRAIL; INSTALL THE FRONT MOUNT (ITEM #2) USING THE PROVIDED SCREW (ITEM #5). NOTE: PRE 2019 MODELS WILL USE THE 50MM LONG SCREWS WHILE THE 2019 MODEL USES THE 70MM LONG SCREWS. DO NOT FULLY TIGHTEN UNTIL THE TUBING HAS BEEN INSTALLED.
3. USING A SMALL FLAT SCREW DRIVER, PRY OFF THE SOFT PLASTIC COVER OVER THE FACTORY GARMENT HOOK. REMOVE THE SCREW AND THE METAL TAB. INSTALL THE REAR SUPPORT BRACKET (ITEM #3) USING THE ORIGINAL FACTORY SCREW. DO NOT FULLY TIGHTEN UNTIL TUBING HAS BEEN INSTALLED.
4. REPEAT PROCESS FOR OTHER SIDE.
5. THE TUBING MUST BE INSTALLED SO THAT THE BENDS AT THE REAR OF THE TUBING ARE BENDING UPWARD.
6. INSTALL ONE SIDE OF THE TUBING (ITEM #7) BY SLIDING THE LONG PORTION THROUGH THE REAR MOUNT AND THEN THROUGH THE FRONT MOUNT. YOU MAY NEED TO PRESS THE BUTTON KEEPER INWARD AS IT PASSES THRU THE MOUNTS. REPEAT THIS PROCESS WITH THE OTHER SIDE OF THE TUBING.
7. USING THE COUPLER (ITEM #1), CONNECT THE CENTERS OF BOTH TUBES.
8. TIGHTEN THE SCREWS EVENLY KEEPING BOTH HALVES OF THE COUPLER SQUARE TO EACH OTHER.
9. USING THE PRESTA CYCLE TORQ-KEY, TIGHTEN THE SCREWS UNTIL THE TOOLS INTERNAL CLUTCH SLIPS. AT THIS POINT THE TORQUE IS SET CORRECTLY.
10. TIGHTEN THE MOUNTING BRACKET SCREWS. DO NOT OVER-TIGHTEN.

INSTALLING THE LOFT PLATFORM

1. LAYOUT THE PLATFORM ON A FLAT SURFACE AND GET ORIENTED WITH ITS SHAPE, NOTING THE POCKET WILL FACE DOWNWARD.
2. THREAD THE FRONT CENTER STRAPS THROUGH THE STRAP MOUNTS YOU INSTALLED ABOVE THE VISOR. ATTACH STRAP TO THE TOP OF THE PLATFORM.
3. WRAP THE FRONT CORNER STRAP AROUND THE END OF THE TUBING AND THE FRONT MOUNT (ITEM #2); ATTACH THE STRAP TO THE TOP OF THE PLATFORM.
4. ON EACH SIDE, PASS THE FABRIC BETWEEN THE HANDRAIL AND TUBING. PULLING TAUGHT, ATTACH THE FLAPS TO THE TOP OF THE PLATFORM.
5. CHECK THAT THE PLATFORM IS CENTERED CORRECTLY FROM SIDE TO SIDE AND SNUG TO THE FRONT BULKHEAD. READJUST TENSION OF CENTER STRAPS IF NEEDED.
6. LACE THE PARACORD FROM THE SIDES TOWARDS THE CENTER. START THREADING FROM THE TOP OF THE GROMMET ON THE FAR SIDE. LACE THE CORD DOWN THROUGH THE GROMMET THEN WRAP AROUND THE TUBING AND DOWN THROUGH THE NEXT GROMMET UNTIL YOU REACH THE CENTER.
7. WORK BOTH SIDES TO KEEP THEM EVEN BY SNUGGING THE CORD AS YOU GET CLOSER TO THE CENTER.
8. ONCE YOU REACH THE CENTER WITH BOTH CORDS YOU CAN USE THE CORD LOCK TO KEEP THE CORDS TENSION SECURE.
9. CHECK THAT ALL STRAPS AND SIDE FLAPS ARE EVEN AND SECURE. ADJUST AS NEEDED.



GEAR LOFT COMPONENTS

ITEM#	PART #	DESCRIPTION	QTY.
1	20102	COUPLER	1
2	20104	SUPPORT_FRONT	2
3	20105	SUPPORT_REAR	2
4	20101	STRAP MOUNT	2
5	988189	CAP SCREW M6x50	2
5a	988193	CAP SCREW M6x70	2
6	PCT4	TORQKEY 4NM.	1
7	20100	TUBING SET	1
8	20103	LOFT PLATFORM	1
9	25301	550 PARACORD	2
10	25302	CORD LOCK 550 PARACORD	1
11	GLMB-I	INSTRUCTION SHEET	1



WARNING: DO NOT EXCEED 5 LBS. PER SIDE ON THIS LOFT. THIS LOFT IS DESIGNED TO SUPPORT LIGHT WEIGHT ITEMS SUCH AS JACKETS, CLOTHING, HATS AND SIMILAR ITEMS WHILE THE VEHICLE IS PARKED AND IS NOT TO BE USED WHILE VEHICLE IS IN MOTION.

PART DESCRIPTION GEAR LOFT, SPRINTER		PART NUMBER GLNVH1144170	
FIND US @ RADIUSOUTFITTERS.COM	QUESTION? WHAT'S YOUR RADIUS	DATE 09/01/2019	
NOTE: SCALE MOUNTAINS NOT DRAWINGS	DRAWN BY: HEAD VAN GEEK		
UNLESS OTHERWISE SPECIFIED:		PROPRIETARY AND NONCONFIDENTIAL	
1. TOLERANCES: FAST FOOD RESTROOMS PODCASTS ON LONG DRIVES SNORING CO-PILOTS THE JOURNEY THERE		THE INFORMATION CONTAINED IN THIS DRAWING IS PROVIDED TO AID IN THE INSTALLATION OF THIS RADIUS OUTFITTERS PRODUCT. ANY OTHER USE IS STRICTLY PROHIBITED WITHOUT WRITTEN PERMISSION OR COMMON SENSE.	
2. WE MAKE PARTS THAT WORK			



INSTALLATION INSTRUCTIONS