



APPLICATION INSTRUCTIONS

COUNTERTOP SEALER 770

PREPARATION

Avoid contact with skin, eyes and clothing. Wash hands after use and do not take internally. Please refer to the product Safety Data Sheet (SDS) before using. The preparation process should be followed to ensure adequate penetration and optimum performance:

Step 1: The concrete substrate must be structurally sound, thoroughly dry and clean. Wait at least 24-48 hours after rain and/or pressure washing before sealing; concrete should be visibly dry.

Step 2: Remove all paints, previous sealers and/or adhesives before application.

Step 3: The substrate must be clean of oil, grease, dirt, wax, curing compounds, efflorescence and other contaminants that might interfere with the penetration of the sealer.

Step 4: If acid is used to clean the concrete, neutralize the surface completely and rinse it with water prior to application. Then wait for the concrete to dry out for at least 24-48 hours.

Step 5: The surface-zone moisture content of the concrete should not exceed 4%wt.

Step 6: Cover all surrounding areas not intended to be coated.

Step 7: New concrete must be cured for at least 28 days before sealing.

APPLICATION

Step 1: Countertop Sealer 770 is a concentrated product that needs to be mixed with water prior to application. We recommend using a bucket to mix the sealer. Pour the 16 oz. container of Countertop Sealer 770 into a bucket.

Step 2: Next fill up the bucket with 48 oz. of water (distilled water is preferred). (Countertop Sealer 770 can be mixed in smaller quantities as long as the one (1) part Countertop Sealer 770 to three (3) parts water ratio is followed. For example, one (1) cup Countertop Sealer 770 can be mixed with three (3) cups of water).

Step 3: Stir the Countertop Sealer 770 and water mixture well before using.

Step 4: Dip either a small nap roller or brush into the bucket of mixed material.

Step 5: Roll or brush one coat onto the countertop.

Step 6: Immediately apply a second coat to the countertop, while the first coat is still wet. Apply until the surface is saturated but not to the point of puddling. (Since the Countertop 770 is a hydrophobic product if you try to apply a second coat after the first coat has dried, the first coat may try to repel the second coat).

Step 7: Roll or brush out any puddles until the sealer penetrates the substrate.



APPLICATION INSTRUCTIONS

Step 8: When the entire application has been treated with two (2) coats, let the concrete dry for at least six (6) hours before light use and at least 24 hours before placing objects back on the countertop and normal everyday use.

Step 9: Clean up: Application tools can be cleaned using soap and water.

Step 10: Unused or old material may be disposed of in a waste disposal site in accordance with local, state and federal laws.

APPLICATION NOTES

- Before application test the sealer by applying in an inconspicuous area to ensure the desired coverage and appearance is achieved.
- Do not over apply.
- Prevent from getting on glazed and finished surfaces such as glass, aluminum etc. In case of contact flush immediately with water.
- Do not use on concrete that has been previously sealed without chemically etching or mechanically scarifying.
- Water repellency may take up to seven (7) days to develop.
- **Maintenance:** The concrete surface can be cleaned with mild soap and water. No citrus or vinegar-based products should be used. Organic does not always mean "mild" and can include citrus ingredients that you'll want to avoid.