



**SINISTER
DIESEL**

(Hot Side)
Charge Pipe
2011+ Ford 6.7L Powerstroke

(Install Time: 1 hour)





DISCLAIMER

- 1) By installing this product onto your vehicle, you assume all risk and liability associated with its use.
 - 2) It is your responsibility to make sure your vehicle complies with all federal, state, and local emissions laws. Federal and many state and local laws prohibit the removal, modification or rendering in-operative of any part of the design affecting emissions or safety on motor vehicles used on a public street or highway. Violation may result in a fine of up to \$32,500 per vehicle (or possibly higher depending on changes in the law). All civil penalties and fines for removing your vehicle's emissions equipment are the sole responsibility of the end user.
 - 3) Due to its high performance nature, this product may void vehicle manufacturer's warranty.
 - 4) Sinister Mfg Company, Inc. is not responsible for misuse of its products. By installing this product, you release Sinister Mfg Company, Inc. of any and all liability associated with its use.
 - 5) Depending on where you live, restrictions may apply. Check all applicable laws before installing or using!
 - 6) The purchaser and end user releases, indemnifies, discharges and holds harmless Sinister Mfg Company, Inc. from any and all claims, damages, causes of action, injuries, or expenses resulting from or relating to the use or installation of this product that is in violation of the terms and conditions on this page, the product disclaimer, and/or the product installation instructions. Sinister Mfg Company, Inc. will not be liable for any direct, indirect, consequential, punitive, statutory, or incidental damages or fines caused by the use or installation of this product.
-



PART:	DESCRIPTION:	QTY:
A	3" Spring Clamps	4
B	3.5" Straight Boot	1
C	4.5" Long Double Hump Boot	1
D	Charge Pipe Turbo Adapter	1
E	O-Rings (pre-installed)	2
F	Charge Pipe Elbow	1
G	Wire Retainer Clip (pre-installed)	1

If you have any issues regarding this product, or if it arrives with missing parts please contact Sinister Diesel directly at (888) 966-6543. Thank you.

IMPORTANT: READ ALL INSTRUCTIONS PRIOR TO INSTALL. Prior to installation, please compare the parts that you have received with the bill of materials provided on this page to assure that you have all the parts necessary for the installation.



CAUTION !!! Never work on a hot vehicle. Serious injury in the form of burns can result if the vehicle has been in use. Allow vehicle to cool prior to installation. Always wear eye protection when working on or under any vehicle.

1 Disconnect both negative terminals on both batteries.

2 Loosen the factory clamp on the intercooler end. Pull boot and charge pipe from intercooler (7mm). If truck is equipped with sensor in charge pipe (2023+ year models), disconnect electrical connector and remove sensor from factory charge pipe. (Image 1)



IMAGE 1

3 Open & remove retainer clip at turbo end of charge pipe (Image 2) with 2 flat head screw drivers. Remove charge pipe from vehicle.



IMAGE 2

4 On coupler end of Turbo Adapter part (D) ensure both o-rings (E) are properly seated (pre-installed). (Image 3)

5 Install boot (C) onto other end of Turbo Adapter (D) with one spring clamp (A) tighten clamp. Press coupler end of Turbo Adapter over the turbo outlet, you should hear a "click". Lightly pull to test it's engaged. (Image 4)



IMAGE 3

- 6** Loosely install 1 clamp (A) over open end of boot (C) (Image 4). Orientate clamp as shown in (Image 6 - left arrow)

Note: Make sure to thoroughly clean & dry stock intercooler outlet that accepts the straight Sinister boot (B) (see image 6 - right arrow)



IMAGE 4

- 7** Install straight boot (B) onto Charge Pipe Elbow (F) and loosely place 2 clamps (A) (Image 5). Install on intercooler outlet.



IMAGE 5

- 8** Press opposite end of Charge Pipe Elbow (F) into turbo side boot (C). (Image 5 - left arrow) Even out the charge pipe and boots ensuring even engagement. (Image 6)



IMAGE 6

- 9** Orientate and tighten all 3 remaining clamps (A)

- 10** If equipped, re-install sensor into threaded port on charge pipe and re-connect electrical connector. (Image 7)



IMAGE 7

Installation is now complete. Start truck and check for air leaks.

SD-INTRPIPE-6.7P-HOT-23

2023



#1 IN PERFORMANCE PARTS & KITS

2025 OPPORTUNITY DR. ROSEVILLE, CA 95678 SINISTERDIESEL.COM