



Product Information Sheet: Mouldable Concrete Filler



RAPID, RELIABLE, HIGH STRENGTH REPAIRS WHICH CAN BE MOULDED INTO SHAPE.

Floorsaver Mouldable Concrete Filler, based on a blend of powder polymers and cement, is used to repair step nosings, kerb edges, broken stonework, etc. It gives a very high strength repair; what makes it different is that the mix becomes pliable and you can use as much or as little as you like – no wastage! Just push a handful in place and then use a wet trowel, knife or gloved hand to mould it into shape. It's hard in 1 hour and rock solid in 2. It is non-dusting and can be painted, or left as it is.

- Easy to mix by just adding water and dries rapidly
- No priming, just push it in and smooth it off
- High strength
- No wastage
- Can be used both inside and outside even in cold conditions
- Repairs 5mm – 100mm deep in one go

HERE'S HOW TO USE IT:

Step 1 - Preparation:

- Use at temperatures above 5°C.
- Use a stiff brush to remove any loose dirt, dust or other contamination. Scrape off as much existing paint as possible.
- Dampen dry surfaces with cold water.

Step 2 - Mixing:

- Only mix as much as you can use in 5-10 minutes.
- The mix ratio is 7 parts powder to 1 part water by volume, or 10 parts powder to 1 part water by weight. A 10kg unit will produce approximately 5L of repair material and cover approximately 1m² at a depth of 5mm.
- It's important to add the powder to the water, not the other way round!
- You can use some powder from the pack and mix with a little water to get the feel of it. It's probably easiest to wear disposable gloves to mix and knead it by hand. Or use a paper cup to help get your 7 to 1 ratio by volume.
- If your initial mix is too dry and crumbly add some water immediately. If the mix is too runny, add some more powder.
- The secret is not to mix any further after 2-3 minutes, since the mixture will have started curing and the structure of the mix will be damaged and crumble.

Step 3 - Application:

- Dampen the area to be repaired with water.
- Push the mixture into place using a wet gloved hand or trowel, then shape as required.
- Each mix is usable for 5-10 minutes at 15°C - 20°C.
- Wash tools in water.

DRYING TIMES:

INITIAL SET	10 minutes at 15°C - 20°C
HARD DRY	1 hour at 15°C - 20°C
FULL STRENGTH	2 hours at 15°C - 20°C

At 10°C and below, drying times will be longer. As a guide allow 24 hours at 5°C. Floorsaver Mouldable Concrete Filler can be painted after 2 hours.

SHELF LIFE:

12 months, if unopened and should not be allowed to freeze.

SEE ALSO:

- **Floorsaver Crack & Hole Filler** – epoxy resin paste for minor surface imperfection and cracks in concrete floors.
- **Floorsaver Pourable Concrete Filler** – pourable cement/polymer based hole filler for heavily used concrete floors.

SAFETY:

- Material Safety Data Sheets are available.
- Product labels provide general safety information.

ORDERING:

Please place your order direct from us online using a debit or credit card. We want you to enjoy using our products and achieve a really good result.

If you have any comments please email us at info@floorsaver.co.uk