

ACCUSPLIT®

X3V Stopwatch

Battery Changing Instructions

When the display on your watch begins to go dim, or if it goes blank, the watch needs a new battery. The watch uses a high capacity CR2032 Lithium battery, which has an expected life of five years.

To change the battery, you will need a set of large jeweler's screwdrivers (including Phillips head).

Note: If this looks too complicated, you can always send your watch back to ACCUSPLIT for battery changing instead. See www.ACCUSPLIT.com/support for details.

1. Turn the watch over and select the correct size Phillips screwdriver (the fastening is very tight, so the screws will strip easily if you use the wrong size or type of screwdriver).
2. Remove all six screws from the back of the case, and set aside so they will not get lost.
3. Gently pry the watch back away from the case front, using the gap near the middle button. The lanyard will also come loose - set it aside.
4. Use a small flat head screwdriver to gently push the silver battery hold-down tab out of the way (it is held in place with spring tension). With the battery hold-down tab out of the way, you can shake or pry the old battery loose.
5. Install a new CR2032 battery with + terminal facing up.
6. Put the lanyard back into its slot in the bottom of the case front.
7. Flip the case back over and gently press it back into the front case of the watch, until it seats. The buttons should now work normally.
8. Replace and tighten the six screws in the case back. Screws must be tight for the watch to be water resistant again.

