

**11** Tighten all the hardware

## ROOF RACK INSTALLATION MANUAL



**HAVE FUN AND A SAFE RIDE!**



[www.afxmotorsports.com](http://www.afxmotorsports.com)

4610 Modern Lane, Laredo, TX 78041 Ph. 956-242-6521

**THIS PRODUCT IS FOR OFF ROAD USE ONLY**

## CAN AM X3

---

## CAN006-F




# THANK YOU!

## FOR PURCHASING AT AFX MOTORSPORTS



## HOW TO INSTALL

Pieces included:



### Hardware:

- (28x) 1/4" x 3/4" Bolts
- (20x) 1/4" x 1/2" Bolts
- (12x) 1/4" x 1" Bolts
- (12x) 1/4" Plain washer
- (60x) 1/4" Lock nut


### Tools needed (Not Included):

- 5/32" Allen Key.
- 7/16" Combination Wrench.

#### Liability Statement

AFX Motorsports products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by AFX Motorsports and is not recommended. AFX Motorsports products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact AFX Motorsports to verify that they will work together. Although AFX Motorsports has thousands of satisfied customers, user should be aware that installing bumpers, rock sliders, spare tire carriers, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. AFX Motorsports urges operators and occupants to wear a helmet and appropriate riding gear at all times. By purchasing and installing AFX Motorsports products, user agrees that should damages occur, AFX Motorsports will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. AFX Motorsports, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from AFX Motorsports. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim. AFX Motorsports will warranty only parts provided by AFX Motorsports. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by AFX Motorsports. AFX Motorsports parts and products are not warranted if item was not installed properly, misused, or modified.

- 10** Settle the legs of the roof rack over the OEM roof (the OEM roof has 3 gaps on each side)



Align the perforations on the roof's gaps to the perforations on each Leg of the Roof Rack.



Front Leg




Center Leg



Rear Leg



Secure the roof rack to the vehicle using 1/4" x 1" bolts with a washer and lock nut on each leg

**8** Join the roof Rack to the Rear legs. Align the perforations and use 1/4"x 1/2" bolts with lock nuts.




\*Make sure the perforations of the rear legs align to the perforations on the rear side.

**9** Join the roof Rack to the center legs. Align the perforations and use 1/4"x 1/2" bolts with lock nuts.




Make sure the perforation of the center legs align to the perforation on the rear side.


**1** Install rear frame assembly onto rear side rails (as it is shown in the image). Use four 1/4x 1/2" screws with nut. (Do not tighten yet)




**2** Align 3 central rails with the perforations (as it is shown in the image). Use twelve 1/4" x 3/4" screws with nut, inserting them bottom-up. (Do not tighten yet)




**3** Install Front frame Assembly onto front side rails (as it is shown in the image). Use four 1/4 x 1/2" screws with lock nut (Do not tighten yet)




- 4** Align 3 central rails with the perforations (as it is shown in the image). Use sixteen 1/4" x 3/4" screws with nut, inserting them bottom-up (**Do not tighten yet**)



- 6** Align the last central rail with the perforations of the Bracket #3 (As it is shown in the image). Use four 3/16 x 3/4" screws with nut, inserting them bottom-up.



- 5** Join the rear rack assembly with the front rack assembly, using the Bracket #1 align the perforations place the bracket on the inside of the roof rack, using eight 1/4" x 1/2" screws with lock nuts (**Do not tighten yet**)



- 7** Join the roof Rack to the front legs. Align the perforations and use 1/4"x 1/2" bolts with lock nuts.

