

— Instruction Manual —

# VB01XL



## Acu-Set Volleyball Trainer

**PARTS LIST**

Item	Qty	Description	Item	Qty	Description
A	1	PB130 Base	B	1	Outer Pole
C	1	Inner Pole	D	1	Hoop
E	1	Net	F	1	Height Adjustment Pin
G	1	Hoop Angle Adjustment Pin	H	1	PB130 Hardware
I	1	3/8" X 3" Hex Bolt	J	1	3/8" Lock Nut

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ◆ **Read all instructions before proceeding.**

1. Using the *PB130 Hardware (H)* and the Instructions included with the *PB130 Base (A)* remove the *PB130 Base (A)* from the shipping pallet and assemble. Using the *3/8" X 3" Hex Bolt* and *3/8" Lock Nut* from the *PB130 Hardware (H)* bolt the *Inner Pole (C)* into the socket on the *PB130 Base (A)*. See Figure 1.
  
2. Attach the *Hoop (D)* to the *Outer Pole (B)* using the *3/8" X 3" Hex Bolt (I)* and the *3/8" Lock Nut (J)*, be sure to feed the *3/8" X 3" Hex Bolt (I)* through the end of the lanyard that is attached to the *Hoop Angle Pin (G)*. Adjust the *Hoop (D)* to the desired angle and install the *Hoop Angle Pin (G)*. See Figure 2.



3. Install the *Net* (E) on to the *Hoop* (D) by rolling the Velcro® straps around the *Hoop* (D) and back on to themselves. See Figure 3.
4. To raise and lower the *Hoop* (D) remove the *Height Adjustment Pin* (F), raise the *Outer Pole* (B), re-install the *Height Adjustment Pin* (F) at the desired height. See Figure 4.

