



## Golden Eagle Mfg. Vacuum Manifold Install

Thank you for your purchase of Golden Eagle Mfg. products for your high performance needs. You now own one of the best products on the market, all 100% made in the **USA!** We are very confident you will be more than pleased with your purchase. If you ever experience any problems, have any concerns or just want to give some advice, we would love to hear from you.

(909) 592 – 4311 or e-mail [sales@goldeneaglemfg.com](mailto:sales@goldeneaglemfg.com)

This is a pretty simple install..

Things you will need.

- ¼" Drill Bit
- 13/64" Drill Bit
- Drill
- ½" ID Vacuum Hose for supply to the Vacuum Manifold
- Vacuum hose for your other vacuum needs
- 2 Hose Clamps for vacuum supply line
- Pipe to hose nipples ( located at almost any hardware store. 1/8 NPT to your desired I.D. hose size )
- Teflon Tape ( located at almost any auto parts or hardware store )

1. Determine how many vacuum lines you will need to run and then drill out that amount of holes on your Vacuum Manifold, Max. 6 lines, using a ¼" drill bit by centering the bit in the tapped hole and drilling carefully staying away from the threads as much as possible. (these holes have already been tapped so there is only a small portion of material to remove)
2. Clean the Vacuum Manifold thoroughly and assemble the fittings back onto the manifold.
3. Find a place to mount the Vacuum Manifold in your engine compartment ( preferably the firewall )
4. Using the manifold as a template, mark two spots to drill your holes.
5. Drill these holes using a 13/64" drill bit.( make sure you are not drilling into an area that will interfere with wiring or any other mechanical lines! )
6. Using the supplied bolts and nuts, mount the Vacuum Manifold to your desired location.
7. Find a large vacuum source from your intake manifold (sometimes the best line to use is the brake booster line, must be at least ½" I.D. hose!!! ), splice the line or route a new line from your intake manifold to your Vacuum Manifold. Make sure the line is secured using hose clamps.
8. Route a line from your Vacuum Manifold to your brake booster (if you used this line for your main vacuum) or to whatever object you spliced the line from.
9. Install the Pipe Thread to hose nipples according to your needs. Use teflon tape around the pipe thread for a good seal.
10. Test you vacuum lines for leaks or otherwise. Make sure every line is secure and routed clean away from the exhaust or moving parts.

Now you are ready to go. If you ever need to add more lines in the future, simply follow instructions #1-3 again. If you need to subtract a line, you can purchase a 1/8" pipe plug from your local hardware or auto part store.

Again, we thank you for your purchase and we are always here for your input.

Golden Eagle Mfg.  
414 Borrego Ct.  
San Dimas, CA 91773  
Ph. (909) 592 – 4311  
Web [www.GoldenEagleMfg.com](http://www.GoldenEagleMfg.com)  
Sales@goldeneaglemfg.com



## Golden Eagle Mfg. Vacuum Manifold Install

Thank you for your purchase of Golden Eagle Mfg. products for your high performance needs. You now own one of the best products on the market, all 100% made in the **USA!** We are very confident you will be more than pleased with your purchase. If you ever experience any problems, have any concerns or just want to give some advice, we would love to hear from you.

(909) 592 – 4311 or e-mail [sales@goldeneaglemfg.com](mailto:sales@goldeneaglemfg.com)

This is a pretty simple install..

Things you will need.

- ¼" Drill Bit
- 13/64" Drill Bit
- Drill
- ½" ID Vacuum Hose for supply to the Vacuum Manifold
- Vacuum hose for your other vacuum needs
- 2 Hose Clamps for vacuum supply line
- Pipe to hose nipples ( located at almost any hardware store. 1/8 NPT to your desired I.D. hose size )
- Teflon Tape ( located at almost any auto parts or hardware store )

1. Determine how many vacuum lines you will need to run and then drill out that amount of holes on your Vacuum Manifold, Max. 6 lines, using a ¼" drill bit by centering the bit in the tapped hole and drilling carefully staying away from the threads as much as possible. (these holes have already been tapped so there is only a small portion of material to remove)
2. Clean the Vacuum Manifold thoroughly and assemble the fittings back onto the manifold.
3. Find a place to mount the Vacuum Manifold in your engine compartment ( preferably the firewall )
4. Using the manifold as a template, mark two spots to drill your holes.
5. Drill these holes using a 13/64" drill bit.( make sure you are not drilling into an area that will interfere with wiring or any other mechanical lines! )
6. Using the supplied bolts and nuts, mount the Vacuum Manifold to your desired location.
7. Find a large vacuum source from your intake manifold (sometimes the best line to use is the brake booster line, must be at least ½" I.D. hose!!! ), splice the line or route a new line from your intake manifold to your Vacuum Manifold. Make sure the line is secured using hose clamps.
8. Route a line from your Vacuum Manifold to your brake booster (if you used this line for your main vacuum) or to whatever object you spliced the line from.
9. Install the Pipe Thread to hose nipples according to your needs. Use teflon tape around the pipe thread for a good seal.
10. Test you vacuum lines for leaks or otherwise. Make sure every line is secure and routed clean away from the exhaust or moving parts.

Now you are ready to go. If you ever need to add more lines in the future, simply follow instructions #1-3 again. If you need to subtract a line, you can purchase a 1/8" pipe plug from your local hardware or auto part store.

Again, we thank you for your purchase and we are always here for your input.

Golden Eagle Mfg.  
414 Borrego Ct.  
San Dimas, CA 91773  
Ph. (909) 592 – 4311  
Web [www.GoldenEagleMfg.com](http://www.GoldenEagleMfg.com)  
Sales@goldeneaglemfg.com



