

TRUNDLES

AUTOMOTIVE LTD

NOTE: IF YOU ARE UNSURE ABOUT GENERAL FITMENT PLEASE CONTACT US BEFORE YOU START FITTING THIS COMPONENT TO YOUR VEHICLE.

TRUNDLES CANNOT BE HELD RESPONSIBLE FOR ANY FURTHER MODIFICATIONS OR DEVIATIONS FROM THE GIVEN INSTRUCTIONS LAID OUT IN THIS FITTING GUIDE.

RECOVERY POINT (RPPAT04) FITTING GUIDE

NISSAN PATROL GU SERIES 3-ON NISSAN D40 NAVARA TOYOTA LANDCRUISER 80/105 SERIES

FITTED TO GU PATROL SERIES 3-ON

1. Each side uses 2 x M14x1.5mm (vertical plane into the chassis). High-tensile bolts supplied, and one factory bolt inserted into the side profile as pictured.
2. Passenger side requires two nuts on wires (supplied) to be installed into the chassis rail; this will require the bumper/bull bar to be removed on some models. Check your chassis before fitment.
3. Ensure three bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.

FITTED TO 80/105 SERIES

- 105" Landcruiser requires 4 x M12x1.25 bolts
- 100" Landcruiser requires 4 x M14x1.5 bolts
- 80" Landcruiser requires 4 x M12x1.25 bolts

1. All models have nuts retained in chassis, ready for fitment. Two bolts per side as supplied; can be mounted to front or rear of vehicle.
2. Ensure two bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.

FITTED TO D40 NAVARA

1. Fitted to factory-retained nuts on L/H side.
2. M12x1.25 high-tensile bolts and retained nuts supplied for R/H side.
3. Ensure two bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.
4. Two bolts per side as supplied; can be mounted to front or rear of vehicle.

HARDWARE SUPPLIED WITH RPPAT04

- 1x RPPAT04L Tow Point
- 1x RPPAT04R Tow Point
- 4x M14 x 1.5 Bolts - Patrol/ 100" IFS Landcruiser
- 2x M14 x 1.5 Nuts on Wires - Patrol L/H Chassis
- 4x M12 x 1.25 Bolts - Landcruisers and Navara D40
- 2x M12 x 1.25 Nuts on Wires - Navara D40



GU Patrol Series 3-On



80/105 Series Landcruiser



D40 Navara

All bolts to be tightened to the appropriate torque value based on nominal size, pitch and grade, or OE manufacturer's specs.

	8.8	10.9	12.9
M10	41-60 Nm	59-85 Nm	65-94 Nm
M12	71-105 Nm	102-150 Nm	114-164 Nm
M14	112-168 Nm	161-240 Nm	182-265 Nm
M16	175-260 Nm	250-371 Nm	282-406 Nm

NOTE: Always use tow points as a matched pair teamed with an equalising bridle during any recovery situation.



Ensure all supplied and specified components are used during the installation of tow points. Failure to do so will significantly reduce the Working Load Limit (WLL) specified for each individual point (5000kgs), which can result in serious injury or death.