

TIME REQUIRED:

DIFFICULTY:

TOOLS REQUIRED:

TIME FRAME



- 10mm socket wrench
- 4mm and 5mm Allen wrench
- T15 Torx wrench
- Phillips head screwdriver

RECOMMENDED RELATED UPGRADES




GP EXHAUST



PREDATOR PROS




STAINLESS BAR ENDS



MULE PASSENGER PEG BLOCK-OFFS

WARNING: Laws concerning this product vary from state/province to state/province. Your state/province may prohibit its use on public roads or restrict its use to novelty, show use, off-road areas, or race facility areas only. In some states/provinces off-road uses are also prohibited. The manufacturer and retailer assume no responsibility for any use or application of this product in violation of any applicable law. Check applicable laws and regulations before installing products.

WARNING: It is recommended that this kit be installed by a certified Triumph technician, following the Triumph service manual to aid in proper fitting. Verify all torque specs in Triumph service manual.




PREP: For this installation, you will need a 4mm Allen wrench, 5mm Allen wrench, 10mm socket wrench, T15 Torx wrench, and a Phillips head screwdriver.




STEP 1: Use a 5mm Allen wrench to remove the two screws on the bottom of the headlight bucket.




STEP 2: Pull the front of the headlight out. Note the tab along the top of the headlight rim and the corresponding cutout on the headlight wire bracket where it mounts.




STEP 3: Use a T15 Torx wrench to remove the headlight wire bracket.



STEP 4: Pull the headlight wire bracket out of the headlight bucket.



STEP 5: Disconnect the turn signal harnesses. The harnesses are the plastic black and white connectors.




STEP 6: Use a 5mm Allen wrench to uninstall the turn signals.



STEP 7: Remove the turn signals.




STEP 8: Mount the new Turn Signals on the turn signal bracket. Use a Phillips head screwdriver to loosen the turn signal so that it can be freely adjusted.




STEP 9: Use a 4mm Allen wrench and a 10mm socket wrench to install the new Turn Signals to the turn signal bracket.



STEP 10: Adjust the new Turn Signals to the desired position and use a Phillips head screwdriver to secure them in place.



STEP 11: Connect the turn signals to the wire harnesses. The black leads connect with the black harnesses, and the red wire from the right turn signal connects with the green wire with the white stripe, and the red wire from the left turn signal connects



STEP 12: Reinstall the headlight wire bracket with a T15 Torx wrench.



STEP 13: Mount the front of the headlight in place.



STEP 14: Use a 5mm Allen wrench to install the two screws on the bottom of the headlight bucket.



Installation complete!