




ACCESSORIES IN PACK:




**ELECTRODE
PADS**



**ELECTRODE
WIRES**



**CHARGING
CABLE**



**STORAGE
BOX**

QUICK START INSTRUCTIONS:



1. Plug Electrode pads into Electrode wires



2. Plug other side of Electrode wires into Comfee at top.

Wires don't have a left and right, either side is fine, you can use one side or both.

3. On the device, the left Ch1 controls the left set of pads and the right Ch2 controls the right set of pads.

4. Once switched on, use the F (function) key to choose TENS, EMS or Fitness. Holding this button down will also adjust the timer between 15, 30 and 45mins.

5. The Ch1 and Ch2 will control the intensity levels. The UP and DOWN will select the different programs/sensation patterns.

6. Remove sticky pad cover and place onto clean dry skin. You're good to go!

OTHER NOTES:

- If you change between functions or programs, the intensity will go back to 1.
- TENS and EMS modes have 20 different programs with 16 levels of intensity.
- Fitness has 10 modes and 16 levels of intensity
- If you do not have the Electrode wires plugged in the device, the Ch intensity levels will not change.
- Device battery lasts for 5 hours. You can gauge levels from the battery symbol or the device intensity will be lower. It will take xx to fully charge the device.

LOOKING AFTER YOUR PADS:

- Attach pads on clean, dry skin.
- You can clean the sticky side of the pad with soap and water however do not get the back or wires wet.
- Always put protective cover back on the pads when not in use.