

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List


PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List

PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List

PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List

PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors
**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.
For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List

PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List

PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List

PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List


PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List


PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.

FT-136 Birds Element Fountain



FOUNTAIN INFORMATION:

This fountain holds approximately 1.5 gallons of water.

**This fountain uses a small fountain cover.
(FTNCOV-SM)**

**Not recommended for use with refill kits or LED
light kits.**

Pump Kit Parts List


PK140 Pump (1)
Approx. 10" length of 1/2" Black Non-Kink tubing (1) **
Approx. 2" length of 5/8" clear tubing **
Hose clamps (2) *
Approx. 9" length of rebar (2)

*Hose clamps may be used as flow restrictors

**Black non-kink tubing and clear vinyl tubing have been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

**PF140 - 140 GPH Pump
6 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly




Made in USA

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-136 Birds Element Fountain

Assemble your fountain on a level surface capable of holding a minimum of 153 pounds with an approximate 1.25 square foot footprint.




FT-135C (66 lbs)
18"L x 10"W x 8"H

1. Position the basin (FT-135C) where the fountain is to be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
3. Place the pump in the basin (FT-135C) next to the gap on the top lip.
4. Lay the pump cord in the lip at the top of the basin (FT-135C).
5. Insert the 2 rebar support pipes into the holes at the back of the basin



FT-136A (69 lbs)
5"L x 10"W x 22.75"H

6. Place the water feature (FT-136A) over the rebar support pipes.
 - a. Check that the water feature (FT-136A) and basin (FT-135C) rest flush.
 - b. Check that the pump chord is not being crushed.
7. Fit the 5/8" clear tubing over the CPVC pipe protruding from the bottom of the water feature (FT-136A).



FT-135B (6 lbs)
6.5"L x 6.75"W x 4"H

8. Place the pump cover (FT-135B) in front of the pump assembly and push back until properly seated.
 - a. Cover should be placed with the finger hole to the bottom.
 - b. Note: If cover is not installed properly, it will not fit in the basin.
9. Fill the fountain with water.