

# FT-17 San Pietro Fountain

**Three people are recommended for the installation of this fountain!**



## FOUNTAIN INFORMATION:

**This fountain holds approximately 20 gallons of water.**

**This fountain uses a medium fountain cover.  
(FTNCOV-MED)**

**Compatible with Refill #7 Device and LED Kit  
(A different style stopper may be requested for the refill kit.)**

## Pump Kit Parts List

PK300 pump (1)  
#7 stopper (1)  
Approx. 24" length of 1/2" black non-kink tubing (1)  
Wedges (4)  
Hose clamps (3)\*

\* Hose clamps may be used as flow restrictors

## TOOLS REQUIRED:

Bubble Level



## PUMP INFORMATION:

**OEMPF320 - 320 GPH Pump  
16 FT cord length**

## - WINTER CARE -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

## - GENERAL FOUNTAIN TIPS -

**Install fountains on a level surface.** You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly



**Made in USA**

Check out YouTube for a "How to" video.

For more Campania product information visit [www.campaniainternational.com](http://www.campaniainternational.com)

# FT-17 San Pietro Fountain

## Three people are recommended for the installation of this fountain!


Assemble your fountain on a level surface capable of holding a minimum of 1012 pounds with an approximate 3.5 square foot footprint.



FT-17F (202 lbs)  
22.5"L x 22.5"W x 6.5"H


1. Place the base (FT-17F) into position where the fountain will be installed, ensuring that it is level.

- a. **Note: Check that all components are leveled as the fountain is assembled.**



FT-17E (175 lbs)  
17"L x 17"W x 20"H

2. Position the large pedestal (FT-17E) over the base (FT-17F).



FT-17D (315 lbs)  
42"W x 9"H

3. Center the large bowl (FT-17D) over the large pedestal (FT-17E).

4. Assemble the fountain plumbing

- a. Using a hose clamp, attach the tubing to the pump outlet.

- b. Place a hose clamp over the other end of the 1/2" non-kink tubing

- c. Place the stopper around the pump cord approximately 8" from the pump.

5. Feed the pump cord all the way through the hole in the large bowl (FT-17D), through the large pedestal (FT-17E), and out of the opening in the bottom of the base (FT-17F).

6. **FIRMLY** press the stopper into the hole evenly.

- a. **Note:** Using the handle of a screwdriver or hammer works best to press the stopper in place.



FT-17C (75 lbs)  
10"W x 19.5"H

7. Place the pump cover (FT-17C) over the pump.

8. Feed the tubing connected to the pump through the top of the pump cover (FT-17C).



FT-17B (56 lbs)  
22"W x 7"H

9. Connect the 1/2" non-kink tubing to the pipe protruding from the bottom of the small bowl (FT-17B) with the hose clamp.

10. Center the small bowl (FT-17B) on the pump cover (FT-17C).



FT-17A (19 lbs)  
7"W x 13.5"H

11. Fit the finial (FT-17A) into the small bowl (FT-17B) by feeding the protruding copper pipe from the bowl into the copper pipe hole in the finial.



FT-17CC (2 lbs)  
6"L x 1"W x 4"H

12. Place the pump cover door (FT-17CC) into the pump cover (FT-17C).

13. Fill the fountain with water.