



THE FITNESS HEADPHONES

<https://rayconglobal.com>

CONTENTS

INTRODUCTION	01
OVERVIEW (FEATURES)	02
WHAT'S IN THE BOX	03
UNIT AT A GLANCE	04
FUNCTIONS	05
SOUND FEATURES	06
USING YOUR HEADPHONES	07
Connecting via Bluetooth	07
Charging Your Device	08
LED Status	09
Quick Swap Ear Cushions	10
ADVANCED FEATURES	11
Multipoint	11
TROUBLESHOOTING / FAQ	12
SAFETY & WARRANTY	13
COMPLIANCE & REGULATORY INFORMATION	14

INTRODUCTION

Introducing your new Fitness Headphones — an audio companion as strong as you are.

At Raycon, we believe in creating innovative tech designed to embrace and empower your every day. We've teamed up with expert engineers, leading taste-makers, and platinum artists to design wireless audio you'll love to use and every day tech that can take whatever life throws your way. We believe in the early risers and the one-more-milers of the world. Premium audio, inspired by you.

To get the most out of your Fitness Headphones, we strongly encourage you to fully read through this user guide. You can also visit our support center at www.rayconglobal.com/support. This web page has more specific guidelines and helpful videos for you to navigate your product. For best performance, charge fully before first use.

FEATURES AT A GLANCE _____

BUILT FOR ACTIVITY

3 Quick Swap Ear Cushions, IPX4 Water Resistance, & 45 Hours of Battery Life

- Take your workouts to the next level with The Fitness Headphones! With Quick Swap Ear Cushions, you can easily switch between three included cushions for the perfect fit. Plus, enjoy peace of mind with superior water resistance and long-lasting battery life, ensuring maximum comfort and performance through any workout.

IMMERSIVE AUDIO

Active Noise Cancellation & Awareness Mode

- Experience unparalleled sound quality during your workouts with advanced headphones equipped with ANC and Awareness Mode! These headphones are designed to enhance your active lifestyle, with ANC to eliminate external noise and Awareness Mode to amplify sounds in your environment.

VERSATILE CONNECTIVITY


Multipoint Technology

- Never sacrifice productivity for physical activity with headphones that feature Multipoint technology! Connect to both your laptop and phone simultaneously, ensuring that you never miss an important call or email, while still being able to enjoy your favorite tunes during your workout.

WHAT'S IN THE BOX




1




2



3



4



5

1. The Fitness Heaphones


2. Type C Charging Cable

3. Quick Start Guide & Compliance Booklet

4. Auxiliary Cord

5. Quick Swap Ear Cushions (3 Sets)

UNIT AT A GLANCE



1. Volume Up
2. Power Button
3. Volume Down Button
4. 3.5mm Auxiliary Input
5. LED Indicator
6. Quick Swap Ear Cushion
7. USB-C Charging Port
8. ANC/Awareness Mode Button
9. Charging LED Indicator

FUNCTIONS / TOUCH CONTROL

1. VOLUME UP CONTROLS

- Volume Up *Tap Once*
- Skip Track *Hold for 2 Seconds*

2. POWER CONTROLS

- Power On *Hold for 3 Seconds*
- Power Off *Hold for 3 Seconds*
- Play/Pause *Tap Once*
- Answer Call *Tap Once*
- End Call *Tap Once*
- Redial the last number *Tap Twice*
- Reject Call *Hold for 2 Seconds*
(While receiving a call)

3. VOLUME DOWN CONTROLS

- Volume Down *Tap Once*
- Previous Track *Hold for 2 Seconds*

4. ANC / EQ CONTROLS

- Balanced Sound *Hold for 1.5 Seconds*
- Bass Sound *Hold for 1.5 Seconds*
- Pure Sound *Hold for 1.5 Seconds*
- ANC On *Tap Once*
- ANC Off *Tap Once*
- Awareness Mode *Tap Once*



SOUND FEATURES

SOUND PROFILE & ACTIVE NOISE CANCELLATION

- ↕↕ Balanced Sound: A leveled sound that is great for all around performance and warmth
- ▮▮▮ Bass Sound: Our bass boosted sound, great for songs with strong beats and a go-to for bass lovers.
- ⦿ Pure Sound: Our most refined sound, perfect clarity to hear every single note.

Tap once to toggle between Noise Cancellation and Awareness Mode


- 👂 Active Noise Cancellation (ANC): Uninterrupted focus by blocking out unwanted noise
- 👂 Awareness Mode: Enhance and stay connected to the world around you by amplifying external noise.




USING YOUR HEADPHONES

CONNECTING VIA BLUETOOTH

1. Hold “⏻” for 3 Seconds to power on. Headphones will enter pairing mode automatically.




2. From the source device, go to Bluetooth settings and ensure Bluetooth is on. Search for “The Fitness Headphones” and select it to pair.




3. To re-enter into pairing mode, hold down the ⏻ and — for 5 seconds. The device will disconnect from any connect device(s).

CHARGING YOUR DEVICE ---


1. Plug the USB-C connector in the charging port, located on the left side.



2. When charging, the LED below the charging port will begin to glow red, indicating the Headphones are currently charging.





3. When fully charged, the Charge LED will turn Blue - your headphones are ready to go!
The complete charging time is approximately 2 hours.





Note: The headphones will not be able to play while charging.

LED STATUS ---

CHARGING LED - LEFT SIDE

LED INDICATION	STATUS	MEANING
	Solid Red LED	Headphones are charging
	Solid Blue LED	Headphones are fully charged

PAIRING LED - RIGHT SIDE

LED INDICATION	STATUS	MEANING
	Alternating Blue and Red Lights	Earbuds are in Pairing Mode
	Solid Blue LED	Earbuds are connected


QUICK SWAP EAR CUSHIONS

CHANGING THE QUICK SWAP CUSHIONS:


Your Fitness Headphones come with 3 pairs of Quick Swap Ear Cushions:

- PU Leather Ear Cushion: Experience ultimate comfort and focus with these snug ear cushions, optimized for noise cancellation.
- Black / Blue Galaxy Mesh Ear Cushions: Designed for your toughest workouts, these breathable ear cushions are easy-to-clean and sweat proof.


1. Hold the Headphones firm in one hand and place your other hand.



2. Turn the cushion counter clockwise around 30 degrees and remove the cushion.




3. With the new Cushion, place the cushion in the removal position (30 degrees counter clockwise) and rotate clockwise until the cushion is secured



ADVANCED FEATURES _____

MULTIPOINT



WHAT IS MULTIPOINT?

Multipoint allows you to connect your headphones to up to two devices simultaneously, such as your smartphone, laptop, or tablet - the combinations are endless!. This means you can easily switch between devices without having to disconnect and reconnect each time. Once you have paired your Fitness Headphones with both devices, they will automatically switch to whichever device is playing audio. With Multipoint, you can connect your headphones to both your phone and your laptop, allowing you to easily switch between your workout playlist and work calls without any interruptions.

HOW DO YOU SET-UP MULTIPOINT?

To use this feature, make sure both devices are within the Bluetooth range and have Bluetooth enabled.

1. Pair the headphones with your first device (e.g. your smartphone).
2. Disconnect the headphones from your first device using the Bluetooth settings on the device. The headphones will re-enter Pairing Mode.
3. Pair the headphones with your second device (e.g. your laptop) via its Bluetooth settings.
4. The headphones will now be able to connect to both of your devices when turned back on.

TROUBLESHOOTING / FAQ ---

HEADPHONES WON'T POWER ON?

- Check that the battery is fully charged - the LED near the charging port will glow red indicating the headphones are charging

HEADPHONES WILL NOT CHARGE?

- Ensure you are using the correct cable - to avoid issues, use the provided cable to charge your Fitness Headphones.
- Verify that the power source is sufficient (wall charger is preferred).

HEADPHONES HAVE NO SOUND WHEN CONNECTED TO A DEVICE(S)?

- Ensure the headphones is within 10 meters (33 feet) of the connected Bluetooth device
- Check the battery level: If the battery level of either the headphones or your connected device is low, it can cause the connection to be weak or to drop.
- Reconnect your headphones by either turning them off and turning them back on or forgetting the Fitness Headphones from your device and re-pair.

HEADPHONES HAVE NO SOUND WHEN CONNECTED BY 3.5MM AUDIO AUX CABLE?

- Check the volume level of the connected device, the music source, and the headphones.
- Ensure that the line connecting the device and the headphones is intact and securely connected.

MULTIPOINT IS NOT WORKING?

- Confirm Headphones are charged and that they are disconnected from any Bluetooth device.
- Confirm Headphones are in pairing mode and reconnect devices to Bluetooth.

HOW DO I CLEAN THE EAR CUSHIONS?

- Remove the Ear Cushions from the headphones before cleaning - do not wash/clean while they are on the headphones.
- Fabric Cushions: Can be hand or machine washed using warm soapy water. Allow to dry for 5-6 hours before using them again.
- PU Leather Cushions: Hand wash only with soapy water / damp cloths, and avoid using harsh chemicals
- Do not allow moisture to get inside the earcups.

SAFETY & WARRANTY _____

SAFETY GUIDELINES

- Be wary of any edges, uneven surfaces, and metal parts, including on accessories and product packaging, to prevent any possible injury or damage.
- Listen to music at a proper volume to avoid damaging your hearing and headphones.
- Do not store in high temperatures, such as in a hot vehicle or in direct sunlight.
- Do not expose the headphones or any of its supplied parts to rain or other liquids for extended periods of time.
- Do not drop or cause undue impact to the headphones.
- Do not modify, repair, or dismantle the product on your own.
- Do not use any diluent or volatile liquid to clean the product.
- Do not use the product in a hazardous location.

SUPPORT

If your device is not functioning properly, please visit www.rayconglobal.com/support for customer support, and we will be more than happy to help you.

LIMITED WARRANTY

Your Fitness Headphones is covered by a limited warranty. Please visit our website at www.rayconglobal.com/warranty for more details.

PRODUCT SPECIFICATIONS

Model: RBH841
Pairing Name: The Fitness Headphones
Bluetooth Version: 5.0
Power Input: DC 5V/1A
Li-battery Capability: 500mAh
Bluetooth Playtime: 45 hours
Charging Time: About 2 hours
Support Profile: A2DP /AVRCP/HFP /HSP
Frequency Response: 20Hz-20KHz
Bluetooth Operating Range: ≤ 10 m

COMPLIANCE & REGULATORY INFORMATION _____

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- The device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Those limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit on a circuit different from that to which the receiver is connected.
- Consult the dealer on an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statements. The device can be used in portable exposure conduction without restriction.

IC WARNING

This device contains license-exempt transmitter(s)/receiver(s) that complies with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

RF EXPOSURE STATEMENT:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.