

CANDEX®

M630222

LED 48ft String Light Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS:

1. When products are used outdoor applications, connect the products to Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
2. Do not mount or place near gas or electric heaters, fireplace, candles, or any sources of heat.
3. Do not secure the wiring of the product with staples or nails.
4. Do not hang objects from the cord, wire, or light string.
5. Do not use this product for other than its intended use.
6. Do not closed doors or windows on the product or light string as this might damage the wire insulation.
7. Do not cover the product with cloth, paper, or any material not part of the product when in use.
8. Read and follow all instructions that are provided with the product.

IMPORTANT! READ CAREFULLY

CAUTION:

1. To reduce the risk of fire; use only type S LED lamps, 1 Watt maximum.
2. To reduce the risk of fire; do not reposition medium base socket contact.

MODEL NUMBER M630222

SPECIFICATION

Voltage: 120V	Total length: 48ft
Wattage per socket: 1W	Set included: 24 LED S14 Filament Shatter Resistant Light Bulb
Overall Wattage: 24w	Bulb Lifespan: 15,000 hours
Socket Base: Medium base (E26)	Location: Wet Location
Length between Socket: 2ft	

CONNECTING MULTIPLE SETS: USING INCLUDED LED BULBS:

1. Add the wattage of each light string together for a maximum total of 1,080 Watts or less only when using LED light bulbs; for a maximum total of 1,200 Watts or less only when using incandescent light bulbs.
2. Do not allow connection(s) to be wet; avoid the connection(s) to expose to rain or water.

USING LED BULBS INCLUDED

MAXIMUM WATTAGE	NUMBER OF LIGHT STRINGS
1 WATT	45 SETS

**CAUTION: DO NOT EXCEED 1080 WATTS
WHEN USING INCLUDED LED BULBS**

USING INCANDESCENT BULBS NOT INCLUDED

MAXIMUM WATTAGE	NUMBER OF LIGHT STRINGS
7.5 WATTS	6 SETS
10 WATTS	5 SETS
11 WATTS	4 SETS
15 WATTS	3 SETS
20 WATTS	2 SETS
40 WATTS	1 SETS

**CAUTION: DO NOT EXCEED 1200 WATTS WHEN
USING INCANDESCENT BULBS**

CAUTION: RISK OF ELECTRIC SHOCK

1. Do not use with extension cord near water or where water may accumulate.
2. Keep lamps at least 16ft from pools and spas. Keep plus and receptacles dry.
3. Do not submerge.
4. Disconnect power source prior to wiring, replacing light bulbs, or servicing.
5. Do not alter the plug.

REPLACING LIGHT BULBS

WARNING – RISK OF ELECTRIC SHOCK

1. Disconnect power source prior placing light bulbs.
2. Do not replace light bulbs during rain or when wet at outdoor setting.
3. Replace light bulb during dry and calm weather condition at outdoor setting.
4. Unscrew existing bulbs by lightly holding the socket in one hand and twisting the bulb counterclockwise. Bubs may be tight in the sockets. This is normal to prevent moisture from getting into the socket.
5. Replace with medium base (E26) light bulbs. Screw bulbs into socket clockwise until top of socket forms a tight seal around the light bulb; and the bulb makes solid contact with the socket.
6. Recommend use of LED Light bulbs for lower wattage consumption; also suitable for incandescent, CFL bulbs.