



Standard Pleated Balloon Shades

9222 C&D

Instructions are for the Standard Pleated Balloon Shade and for the Relaxed Pleated Balloon Shade. Instructions for a London Shade is in pattern 9316.

Fringe (and other trims) can be added to the bottom edge.

As they are pulled up, all types of balloon shades will have pouffy, un-precise, fluffy folds. If you wish these folds to lay in a more controlled, stacked manner, they will need to be placed by hand each time they are pulled.

Fabric Suggestions: While deciding on your fabric, keep in mind weight and window width. If your fabric and lining are heavy and your window is over 100" wide, you may need a motorized lift system. Blackout lining and interlining can be used. Unlined sheer fabrics are not recommended.

YARDAGE

The finished length of shades are determined by their shortest point.

VIEW C Shade Width: Figure for flat sizes, plus 8" for pleats, plus returns, plus 4" side hem at each side, plus any necessary seams.

VIEW D Shade Width: Figure for flat sizes, plus 12" for pleats, plus returns plus 4" side hem at each side, plus any necessary seams.

CUT LENGTHS

Shade fabric..... Finished length plus 20".

Lining Finished length plus 14".

Interlining..... Finished length plus 14".

Encased Lift cord tape Finished length plus 15". (one length per pleat)

Sure Shade™ Lift System
www.RowleyCompany.com

There is a revolution in window treatments involving lift cords as we have known them. Cords at the back of a fabric shade can pull out and form a loop. A young child can become tangled in the cords and be strangled. The Sure-Shade™ System components, upon using the appropriate fabrication techniques, will meet the standards of the American National Standards Institute (ANSI) dated September 3, 2010. Bead chain, or cord loop, complies with the standards if properly installed to the wall and the Universal Drive Tension Device is used.

Instructions in this package include using the Sure Shade™ lift system components involving the EZ-Rig™ and the encased lift cord tape. The components needed are listed inside. Simplified instructions to assemble the system is also given. Contact the Rowley Company to order the supplies, or a kit.

This lift system must be installed to a mount board, or to the wall, if a pole is used for the shade.