SPA WEEKLY MAINTENANCE



It is extremely important to ensure that your spa is properly maintained on a weekly basis. Your weekly maintenance will protect your spa equipment and keep the water safe from organic build up and harmful bacteria.

- Test your spa water using test strips. Not all test strips are used the same way, so be sure to follow the instructions on the bottle to get the most accurate results. A water sample should be brought in once a month for a more accurate check and balancing instructions. If something is severely off with the balance showing up on your test strip, you should bring a sample in **before** adding anything to your spa.
- Remove your spa filter and rinse it o with a garden hose or under the faucet. Never use a pressure washer to rinse your filter. The fibers on your filter are specially manufactured to catch small debris and particles so your spa will look and feel great. Pressure washing your filter will only tear these fibers open and your filter will then allow small debris to pass through. A soft rinse is all that is needed on a weekly basis.
- Add the required maintenance dose of **Stain & Scale** directly to the water. This will prevent the erosion of your heating element as well as protect your jets and equipment from the harsh effects of bromine, chlorine or salt water.
- Add the required maintenance dose of **Super Soft** by broadcasting it over the surface of the water. **Super Soft** will enhance the look and feel of the water by helping to keep pH levels stable.
- Sprinkle one pouch of **Spa Shock** around the surface of the water. Even if your test strip indicated a sanitizer reading, you should use **Spa Shock** every week to oxidize and burn off any foreign waste in the water. If there is no sanitizer reading, add the recommended dose of **Spa Sanitizer/Chlorinating Concentrate** or **Brominating Concentrate** to the water.
- Top up your feeder with **Chlorine Tablets** or **Bromine Tablets**. Your feeder should have no more than 3–4 tablets in it at one time. Over filling your feeder can actually inhibit the release of sanitizer into the water.
- Always add chemicals to water and make sure the jets are running so chemicals are circulated properly through the spa.

Helpful Tips:

Always leave your spa cover open for a minimum of 1 hour after adding chemicals.

Using enzyme treatments on a weekly basis will prevent the formation of scum lines, organic staining, foaming and surface oils. They will also allow sanitizer residuals to last longer.

Pool Questions? For GREAT ADVICE visit: discounterspoolandspa.com/GREATADVICE