
EHOPPERUSER MANUAL



Body position in the air:

- **1.** Stop pedaling ~6 meters before the kicker and stand on your pedals. The crank arms should be parallel to the ground.
- 2. Keep your hips above the axis of the rear wheel.
- 3. Lean your torso forward.
- 4. Slightly bend your elbows.
- **5.** Keep your head straight, look forward and not under your wheels.
- **6.** Before the jump, lower your seat as much as possible.



Use it responsibly.

Go through all the steps before riding to ensure safety. If you have the opportunity, train together with more experienced riders. Good luck at improving your riding skills!




MTB HOPPER is designed for longevity, to withstand any weather and provide good grip with tires. We recommend to store it in a **dry place**.





It is recommended to wear knee pads, gloves and other safety equipment.




Momentum speed for beginners: 12 km/h - 20 km/h (7 mph - 12 mph). Feels similar to your running speed.










GEOMETRY SETTINGS OF COACH RAMP



PACKING INSTRUCTIONS ≥ ≥ 0.