



Scan for full manual

## VM-2H2 Quick Start Guide

This guide helps you install and use your VM-2H2 for the first time.

Go to [www.kramerav.com/downloads/VM-2H2](http://www.kramerav.com/downloads/VM-2H2) to download the latest user manual and check if firmware upgrades are available.


### Step 1: Check what's in the box

- ✓ VM-2H2 4K HDMI 2.0 1:2 DA
- ✓ 1 Power supply (5V DC)
- ✓ 4 Rubber feet
- ✓ 1 Quick start guide

### Step 2: Mount VM-2H2

Install VM-2H2 using one of the following methods:


- Attach the rubber feet and place the unit on a flat surface.
- Fasten a bracket on each side of the unit and attach it to a flat surface (see [www.kramerav.com/downloads/VM-2H2](http://www.kramerav.com/downloads/VM-2H2)).
- Mount the unit in a rack using the recommended rack adapter (see [www.kramerav.com/product/VM-2H2](http://www.kramerav.com/product/VM-2H2)).



- Ensure that the environment (e.g., maximum ambient temperature & air flow) is compatible for the device.
- Avoid uneven mechanical loading.
- Appropriate consideration of equipment nameplate ratings should be used for avoiding overloading of the circuits.
- Reliable earthing of rack-mounted equipment should be maintained.
- Maximum mounting height for the device is 2 meters.

### Step 3: Connect inputs and outputs

Always switch OFF the power on each device before connecting it to your VM-2H2.



To achieve specified extension distances, use the recommended Kramer cables available at [www.kramerav.com/product/VM-2H2](http://www.kramerav.com/product/VM-2H2). Using third-party cables may cause damage!

---

## Step 4: Connect power

Connect the power cord to **VM-2H2** and plug it into the mains electricity.

Safety Instructions (See [www.kramerav.com](http://www.kramerav.com) for updated safety information)



**Caution:**


- For products with relay terminals and GPIO ports, please refer to the permitted rating for an external connection, located next to the terminal or in the User Manual.
- There are no operator serviceable parts inside the unit.

**Warning:**

- Use only the power cord that is supplied with the unit.
- Disconnect the power and unplug the unit from the wall before installing.

---

## Step 5: Set DIP-switches



SETUP

Set the DIP-switches according to your needs using the following table:

	Programming mode	HDCP Input (MAC mode)	Force RGB	Lock Default EDID
DIP	1	2	3	4
OFF (up)	Normal mode	HDCP enabled	Force RGB	EDID not locked
ON (down)	Enable programming	HDCP disabled	Normal mode	EDID locked