



1. Engage hooks of rails in slots of headboard and footboard at full size position, with horizontal flange of rail protruding outward, as shown. Tap all hooks securely into slots of bed end.
2. Insert threaded glides into legs.
3. Attach cross braces to side rails with nuts and bolts. Do not fully tighten.
4. Slide clamp over one cross brace.
5. Swing the two cross braces together to overlap in the center of the bed. Slide clamp to overlap both cross braces and tighten. Fully tighten the cross brace bolts.
6. To attach four mattress foundation retainer brackets, insert bolt through slot in bracket and hole in rail. Place lock washer on bolt and fasten with nut.
7. If adjustable glides do not touch floor, it may be necessary to attach extension legs.
8. Place box spring on rails (center). Push brackets against box springs. Tighten nuts with pliers.