

Product Overview

- a. Power Button
- b. Mat Sensor
- c. Carrying Handle
- d. Battery Indicator Lights
- e. Charging Port
- (On opposite side)
- f. Wheel
- g. Training Bar
- h. Training Bar Screws (x4)
- i. Side Plate
- j. Charger
- k. Charging Cable



Specs & Features

- Product Dimensions: 10.6" (L) x 5.5" (W) x 4.5" (H) (Each)
- Weight Limit: 220 lbs
- Product Weight: 6.0 lbs (Each)
- Wheel Size: 3.5"
- Max Speed: 7 mph
- Max Range: 6 miles
- Battery: 25.9V, 1.9Ah Lithium-Ion (Each)
- Motor: 250W Hub Motor (Each)
- Charger: 100-240V
- Charging Time: Up to 3 Hours
- Climbing Angle: Up to 10°
- Recommended Age: 13+

Please Note: Images may not reflect exact appearance of actual product.

Getting Started

Charging your MotoKicks


- Only use the included charger.
- Plug the charger into the wall before the charging port.
- Never turn on the **MotoKicks** while they are charging.
- Charge the battery until it is fully charged before using — up to 3 hours.
- Replace the cover over the charging port when done.
- Never leave the **MotoKicks** charging overnight.

• Charger Indicator Light:

- - Charging
- - Charge Complete




Battery Indicator Lights



Important: As a safety precaution, **Motokicks** will automatically turn off when they battery charge level goes below 10%.

How to Recalibrate

If your **Motokicks** are not performing as they should, are beeping or spinning, or feel off balance, their internal balance mechanisms need to be realigned. This is called "recalibrating."



Follow these 3 simple steps:

1. Turn the **MotoKicks** off and place them on a flat, level surface.
2. Hold each Power Button for about 5 seconds until the lights flash and the **MotoKicks** beep.
3. Restart the **MotoKicks** by turning them off and then back on.

Note: it can take up to 3 recalibration attempts to achieve proper internal alignment.

* Keep the **MotoKicks** leveled and still throughout the recalibration process. While recalibrating, do not lean on or put any weight on the **MotoKicks**.

How it Works

If you can ride a hoverboard, you can ride Jetson **MotoKicks**.

- **Power On:** Place on level ground, then turn on each **MotoKick** by quick-pressing the Power Button.
- **Balance Mode:** Gently tilt both **MotoKicks** and they will self-stabilize.

Riding your MotoKicks



1. Lean slightly forward to move forward. **You got this!**



2. Lean slightly backward to move in reverse or brake.




3. Turn by leaning to the side as you ride. **Way to go!**




4. Step off when the **MotoKicks** are at complete stop. Just step backwards one foot at a time. **Great riding!**

Helmet Safety




Proper positioning:
The forehead is covered by the helmet.



Improper positioning:
The forehead is exposed.
A fall could result in serious injury.

* Wear a helmet, appropriate clothing, shoes, and safety gear. Avoid clothing that can get caught into or under the wheels. Closed-toe, flat shoes are recommended. Wear an ASTM F1492 approved helmet and protective gear to prevent injury in the event of an accident.

Master your MotoKicks!
Scan this for more riding tips.



Attaching the Training Bar

The training bar add stability for learning and mimics the feeling of riding a hoverboard.



1. Locate the two screws and side plate on the charging port side of each **MotoKick**.
2. Loosen and remove the screws by turning them counterclockwise with a Phillips-head screwdriver.
3. Use the end of the screwdriver to lift the edge of each side plate up and remove the plates from the **MotoKicks**.
4. Store the plates and the 4 removed screws for future use.
5. Position the two **MotoKicks** on a flat surface so that the sides with the removed plates are facing each other and the Jetson logo atop each **MotoKick** is oriented in the same direction.
6. Align the notches on one end panel of the training bar with the notch spaces at the top of the area vacated by the side plate. Position the panel so that it is flush on the side of the **MotoKick**.
7. Grab 2 of the 4 screws that came with the training bar. Using the screwdriver, insert and tighten 1 screw into each of the 2 screw holes to secure the training bar end panel onto the **MotoKick**.
8. Repeat steps 6 and 7 on the other **MotoKick** with the other end panel of the training bar and the remaining 2 screws.

Important: Do not carry the MotoKicks by the training bar.

Care & Maintenance

RIDING RANGE

The maximum range per battery charge is 6 miles. However, many factors will affect how far you can go per charge:

- Riding Surface: A smooth, flat surface will increase riding distance.
- Weight: More weight means less distance.
- Temperature: Ride, charge, and store the **MotoKicks** above 50°F.
- Maintenance: Timely battery charging after each use will increase riding distance.
- Speed and Riding Style: Frequent starting and stopping will reduce riding distance.

CLEANING

To clean the **MotoKicks**, first make sure they are turned off and the Charging Ports are covered. Carefully wipe with a damp cloth, then dry with a dry cloth. Do not apply water directly to the **MotoKicks**, as the electrical and electronic systems may get wet, resulting in a malfunction of the **MotoKicks** that could lead to personal injury.

BATTERIES

- Keep away from fire and excessive heat.
- Avoid intense physical shock, severe vibration, or impact.
- Protect from water or moisture.
- Do not disassemble the **MotoKicks**.
- If there are any issues with the batteries, please contact the Jetson Care Team.

STORAGE

- Fully charge each battery before storing. Each battery should be fully charged once a month during extended periods of non-use.
- To protect against dust, cover the **MotoKicks**.
- Store the **MotoKicks** indoors, in a dry place, and at a temperature above 50°F.

Warranty

ONE-YEAR GENERAL LIMITED WARRANTY

All new Jetson products, excluding parts and accessories, are warranted against defects in materials and workmanship for a period of one year from the date of original retail purchase when used in accordance with Jetson's user manuals (refer to ridejetson.com/support). **Under this warranty, you will be able to direct your claims to Jetson even in situations where you purchased the Jetson Product from one of our authorized retailers.** To read the full terms of our warranty, visit ridejetson.com/warranty.

**Jetson's top two riding rules:
Be safe. Have fun!**

Safety Warnings

- Before use, please read the user manual and safety warnings carefully, and make sure you understand and accept all the safety instructions. The user will be responsible for any loss or damage caused by improper use.
- Before each cycle of operation, the operator shall perform the preoperation checks specified by the manufacturer: That all guards and pads originally supplied by the manufacturer are in proper place and in serviceable condition; That the braking system is functioning properly; That any and all axle guards, chain guards, or other covers or guards supplied by the manufacturer are in place and in serviceable condition; That tires are in good condition, inflated properly, and have sufficient tread remaining; The area that the product is to be operated should be safe and suitable for safe operation.
- Components shall be maintained and repaired in accordance with the manufacturer's specifications and using only the manufacturer's authorized replacement parts with installation performed by dealers or other skilled persons.
- Warning against recharging non-rechargeable batteries.
- Don't allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts, wheels, or drive train, while the motor is running.
- This product should not be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction (IEC 60335-1/A2:2006).
- Unsupervised children should not play with the product (IEC 60335-1/A2:2006).
- Adult supervision is required.
- The rider should not exceed 220 lb.
- Units shall not be operated to perform racing, stunt riding, or other maneuvers, which may cause loss of control, or may cause uncontrolled operator/passenger actions or reactions.
- Never use near motor vehicles.
- Avoid sharp bumps, drainage grates, and sudden surface changes. Scooter may suddenly stop.
- Avoid streets and surfaces with water, sand, Plasmal, dirt, leaves, and other debris. Wet weather impairs traction, braking, and visibility.
- Avoid riding around flammable gas, steam, liquid, or dust that could cause fire.
- Operators shall adhere to all of the manufacturer's recommendations and instructions, as well as comply with all laws and ordinances: Units without headlights shall be operated only with adequate daylight conditions of visibility, and; Owners shall be encouraged to highlight (for conspicuity) using lighting, reflectors, and for low-riding units, signal flags on flexible poles.
- Persons with the following conditions shall be cautioned not to operate: Those with heart conditions; Pregnant women; Persons with head, back, or neck ailments, or prior surgeries to those areas of the body; and persons with any mental or physical conditions that may make them susceptible to injury or impair their physical dexterity or mental capabilities to recognize, understand, and perform all of the safety instructions and to be able to assume the hazards inherent in unit use.
- Do not ride at night.
- Do not ride after drinking or taking prescription medication.
- Do not carry items when riding.
- Never operate the product barefooted.
- Always wear shoes and keep shoelaces tied.
- Make sure your feet are always placed securely on the deck.
- Operators always shall use appropriate protective clothing, including but not limited to a helmet, with appropriate certification, and any other equipment recommended by the manufacturer: Always wear protective equipment such as helmet, knee pads, and elbow pads.
- Always give way to pedestrians.
- Be alert to things in front and far away from you.
- Do not allow distractions when riding, such as answering the phone or engaging in any other activities.
- The product cannot be ridden by more than one person.
- When you ride the product along with other riders, always keep a safe distance to avoid a collision.
- When turning, be sure to maintain your balance.
- Riding with improperly adjusted brakes is dangerous and can result in serious injury or death.
- The brake may become hot while operating, do not touch the brake with your bare skin.
- Applying brakes too hard or too suddenly can lock up a wheel, which could cause you to lose control and fall. Sudden or excessive application of the brake may result in injury or death.
- If the brake loosens, please adjust with the hexagon wrench, or please contact the Jetson Care Team.
- Replace worn or broken parts immediately.
- Check whether all safety labels are in place and understood before riding.
- The owner shall allow the use and operation of the unit after a demonstration that such operators can understand and operate all components of the unit before use.
- Do not ride without proper training. Do not ride at high speeds, on uneven terrain, or on slopes. Do not perform stunts or turn abruptly.
- Recommended for indoor use.
- Prolonged exposure to UV rays, rain and the elements may damage the enclosure materials, store indoors when not in use.

California Proposition 65

⚠️WARNING:

This product can expose you to chemicals including Chromium (hexavalent compounds), which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to: www.P65warnings.ca.gov.

MODIFICATIONS

Do not attempt to disassemble, modify, repair, or replace the unit or any components of the unit without instruction from the Jetson Care Team. This will void any warranty, and can lead to malfunctions which may cause injury.

ADDITIONAL OPERATION PRECAUTIONS

Do not lift the product off the ground while it is on and the wheels are in motion. This can result in freely spinning wheels, which may cause injury to yourself or others nearby. Do not jump on or off the product, and do not jump while using it. Always keep your feet firmly planted on the foot rest while in operation. Always check the battery charge before using.

NOTICE OF COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/ TV technician for help.
- Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

DISPOSAL OF USED BATTERY

Battery may contain hazardous substances which could endanger the environment and human health. This symbol marked on the battery and/ or packaging indicates that used battery shall not be treated as municipal waste. Batteries should be disposed of at an appropriate collection point for recycling. By ensuring the used batteries are disposed of correctly, you will help preventing potential negative consequences for the environment and human health. The recycling of materials will help to conserve natural resources. For more information about recycling of used batteries, please contact your local municipality waste disposal service.

Stay connected.

Be sure to follow [@ridejetson](https://twitter.com/ridejetson)

on social media to learn about fantastic offers, giveaways, and all the latest Jetson news.



Loving your ride?

Then be sure to leave a review at ridejetson.com/reviews. We can't wait to hear from you!

JETSON

#MakeMoves

Questions? Let us know.

ridejetson.com/support
ridejetson.com/chat

To exercise your product's 1-year limited warranty or inquire about warranty coverage, contact us directly.

US/CANADA: 1-888-976-9904

Manufactured in Shenzhen, China
Imported by Jetson Electric Bikes LLC.
P.O. Box 320149, 775 4th Ave #2, Brooklyn, NY 11232

www.ridejetson.com



Made in China
Date Code: 09/2022

Document Edition: v3.0

© 2022, JETSON. ALL RIGHTS RESERVED. Manufactured by JETSON ELECTRIC BIKES LLC. No portion of this document, including shape, copy, graphics, and design, may be reproduced or transmitted in any form or by any means.