



THE INSTRUCTIONS

Please read this The instructions carefully before using

Thank you for choosing the WOPET intelligent product, in order to guarantee your personnel and property safety, please read this The instructions carefully before using. Under no circumstances shall WOPET be liable to pay compensation or damages to any person or any loss, injury, or damage, unless it's explicitly stipulated in the laws, whatsoever occasioned by this product or as a result of not following the items and conditions and precautions laid in this The instructions.

About The instructions

The authorization of The instructions, trademark and font size are owned by WOPET and its affiliated party; in case the items and conditions laid in this The instructions are not identical with The actual product (including the APP), the actual product (APP) shall be prevailing. WOPET shall, subject to the law, reserve the rights to modify items and conditions laid in this The instructions without further notice, as well as the final interpretation of it. Objection to The instructions, if any, shall be raised in writing by the customers in 7 (seven) days after purchasing, otherwise, it's assumed that the customer has completely accepted and understood all terms and conditions of The instructions

Statement of Authorization

This APP (WOPET) shall keep and protect the individual authority of all users; in order to provide more accurate and personalized service to you, this APP shall be used in accordance with the authorization, and sharing the operating right of your equipment. This APP shall be very careful with these information. Unless otherwise specified in this Statement of Authorization, this APP shall not disclose these information to the third party without your permission.

If you have shared the authorization to another user, he/she shall have such authorization of this equipment as camera, photograph, listening, etc. In case the equipment user has decided to share the authorization, it means he/she has fully understood the items and conditions mentioned above, and our company shall not be held the responsibility for such sequences as privacy disclosure, disputes, property and credit losses, etc. Our company reserves the right of final interpretation of this authorization clause, and has the right to terminate the service agreement with the authorized user immediately.

SCAN TO DOWNLOAD

WOPET INTELLIGENT DOG CAMERA USER MANUAL

Android



Apple



WOPET at a Glance



"SET" Button: Quick press to pop a treat, Long press for 5 seconds to restore factory settings



In order to optimize the equipment performance, it's better to use it at the location where is 10m around the WiFi transmitting device, and in the barrier-free environment.



Log in with your account number and password, click the sign "⊕" at the top right corner after entering the interface Enter the interface of select device model, and select the specific device you want to link.




Long press the button "Set" 5 seconds, after hearing the voice of "beep", select the mark "O" and click the button "Next". Input the WiFi account number and password which connected to the current phone, this equipment can't support the 5G network as present.



Use your equipment camera to scan the APP generated QR code, after hearing the voice of "beep" select the mark "O" under the QR code and click the button "Next" to enter the WiFi connection interface.





In case it's impossible to scan the QR Code for a long time due to the environmental factors, you can enter the hotspot connecting mode and press the link under the QR code, Operation completed, but no prompt tone was heard, after entering the hotspot connecting interface, please follow the interface prompts and complete the connection.



Long press the button "Toss a treat" for 5 seconds.
Tossing Food Interface.



Press the button  at the top right corner of tossing food interface to enter the "Set" interface, then set the relevant items by yourself.



Press the button "My" at the bottom right corner to exit the tossing food interface, and enter the "Set" interface, then set the relevant items by yourself.



In case any trouble occurs to this equipment, and you don't understand the specific handling method at this time, please press the "Service" button and send your questions to us, we will reply by e-mail as soon as possible.

Product Parameters

Product name: WOPET INTELLIGENT DOG CAMERA

Product Size: 147*147*254mm

Net weight : 1.1KG

Barn Reserves : 0.5L

Product Materials: ABS

Camera: 123° HD night vision and wide angle camera.

WiFi band 2.4G

APP installation requirement Android5.0/iOS7.0 or above

Adapter Parameters : Input: 110-220V, 50/60HZ, 0.4A
Output: 5.0V, 1000mA

Technical specifications of the WOPET intelligent dog camera

Function/Item	Functional	Trouble Descriptions		
WOPET INTELLIGENT DOG CAMERA	Set button	1. Quick press (shorter than 1s) to manually pop a treat.		
		2. Under the configuration mode, the green lamp is flickering slowly (0.5s ON and 0.5s OFF).		
		3. Under the configuration mode, in case there's no food in the grain bucket, quick press (shorter than 1s) and the red and green lamps shall flicker alternately.		
		4. Under the configuration mode or the network is connected, long press this button for more than 5s, reset and scan the QR code after hearing the "beep" ; after hearing another prompt, the green lamp shall quick flickering at first, then normally on after the network is connected.		
	Red and green indicator lamp	Red lamp	Green lamp	Status description
OFF		Slow flickering	Configurable status	
OFF		Quick flickering	connecting to the network	
OFF		Normally ON	The network is connected	
	Slow flickering	OFF	No food in the grain bucket, or the food is blocked.	

Precautions:

1. Don't drag the power line directly when plugging or unplugging the adapter.
2. Don't put or insert any foreign matters in this product.
3. It's prohibited to refit or repair the product by yourself.
4. Please use the original power adapter and power line.
5. It's only applicable to use this product indoor, please prevent it from the direct sunlight.
6. It's only allowed to put the dry dog food or snacks in the barn, which size shall within the range of 5~15mm.
7. This equipment is equipped with various kinds of electronic components, and it can't realize the function of water-proof, it's not recommended to use this equipment in the humid environment.
8. Don't use this product for other purposes expect feeding pets.
9. When tossing the dog food or snacks, pay your attention to the surround environment, don't toss the objects to the human or pet eyes.
10. Please clean up the residual dog food or snacks after eating by your pets, and prevent kids from eating by mistake.
11. For the persons without full capacity for civil conduct, lack of experience and knowledge (including the children), they must use, clean and maintain this product under the supervision and guidance of guardian.
12. In case such troubles as abnormal smell, smoking, or abnormal heating has occurred to this product, stop it immediately and feel free to contact the customer service staff.

Common troubles

1. When pressing the button "Toss a treat", the dog food or snack is tossed twice or for three times.
Cause: if the sense lamp doesn't detect the food, it will toss again, and it shall toss four times at maximum.
2. The APP has displayed the prompt of "excessive food".
Cause: the snack outlet of equipment is blocked by foreign matters, please remove the foreign matters in time.
3. The APP has displayed the prompt of "no fodder".
Cause: the equipment can't sense any fodder in the grain bucket, check the grain bucket has fodder in it; or the equipment is exposed to the direct sunlight, please move it to a cool place.
4. It's impossible to continuously watch the video.
Cause: Ensure the power is normally supplied to you intelligent equipment; check the network of your phone and the intelligent is normally connected.
5. Suddenly, the user can't enter his/her APP account.
Cause: firstly, ensure the network is normally connected; secondly, ensure the account number isn't used by other personnel at this time. Otherwise, we recommend to remove this APP, then install it again and try to log in.
6. If the user want to change his/her WOPET APP account number, what shall he/she do?
Cause: Our APP can't realize the function of directly change the account number; if you want to change it, please register a new APP account number by a new e-mail. Then unbound the intelligent equipment to the original account number, and bound it to the new one. Note: If the user wants to bound or rebound the intelligent equipment to the newly registered account number, long press the "Set" button for 5s, after hearing the prompt of "Beep" and the green lamp is slow flickering, scan the QR Code to bound or rebound the intelligent equipment to the new account number.