




Modern Straight-Line Drainage

- Ideal for paths, driveways and areas with limited space such as balconies
- Made in Australia from tough, durable and light-weight, UV-stabilised recycled plastic
- Hold down feet to stop floatation during pouring of concrete
- 9 bottom outlet positions to choose from
- All grates comply to Australian Standards


Easy interchangeable clip-in grates. Suits all RELN channel grates

Lock Rain Mate ends together easily to create sturdy, longer channels



Anti-Floatation Feet

Components:



9 Bottom Outlets to choose from.





Bottom Outlet fits 90mm PVC Stormwater pipe



Rain Mate - Modern Straight - Line Drainage

RELN Rain Mate is our modern straight line drainage, ideal for paths, driveways and areas with limited space such as balconies. Choose which grates you want and easily clip them into place. This range is your property's best mate when it rains.

> Rain Mate (1000 x 119 x 75mm) D.I.Y. Complete Drainage System



- Ideal for paths, driveways and areas with limited space such as balconies
- Designed to withstand 5 tonne vehicle weight
- Tough, durable and lightweight UV stabilised recycled plastic
- Australian Made
- Lock-in clips reduces channel movement
- Hold down feet to stop floatation during pouring of concrete
- Available in all RELN grates
- Easily interchangeable clip in grates
- 9 bottom outlets to choose from, for maximum flexibility

- Bottom outlet adapter for quick and easy installation available
- Bottom outlet fits 90mm PVC stormwater pipe

Grate Options: (11.3cm x 2.5cm x 1m): Plastic in Black, Sandstone, Terracotta, Portland Grey and Heritage Green. Black Heel Guard Plastic, Architectural, Stainless Steel, Galvanised Steel, Civil Ductile Iron.

Risers: 1m Channel, End Cap, Leaf Guard, Bottom Outlet Adapter

Display: Hang Pad and Flyer available

> Frequently Asked Questions

Q1. What is the difference between Storm Mate and Rain Mate?

A. Both are great for straight-line drainage, however Rain Mate comes with 9 bottom outlet options for maximum design flexibility, and a bottom outlet adapter which fits 90mm PVC stormwater pipe.

Q2. What is the best grate for busy pedestrian areas?

A. Rain Mate, Rain Drain and Drain Trade can all be fitted with RELN's Heel Guard plastic grate or RELN's 316 Stainless Steel Architectural grate. Both have a residential wheel loading of up to 1.5 Tonnes when installed correctly.

Q3. Can I change or replace the grate at a later stage?

A. Yes, all Reln grates Traditional, Heel Guard Galvanised, Stainless, Architectural and Ductile interchange with Reln complete channel range.


Q4. Can I use the same grate on Rain Mate, Rain Drain and Rain Drain Trade?

A. All our grates for Storm Mate, Storm Drain, Rain Mate, Rain Drain and Rain Drain Trade are interchangeable, and fit each channel perfectly. Simply click grate into channel!



Drainage Planner

Design your own drainage system




End Cap

Qty required



Leaf Guard

Qty required



1m Channel

Qty required



Bottom Outlet

Qty required

four simple steps



1. Prepare Ground

- Prepare ground with 50mm deep compacted sand base
- Allow for a minimum of 100mm backfill of concrete on each side
- Fix a

string line to set finished surface level • For best run-off allow for a fall of approx 5mm every 1m length



2. Lay Out
ASSEMBLE CHANNEL & GRATE PRIOR TO INSTALLATION

- Lay out Rain Mate® to check installation
- Locate pipe outlet at lowest


end of installation • Cut out bottom outlet hole to suit • Rain Mate® can be cut to length with saw



3. Join Components

- Join channels - fit End Cap at each end
- Joints and End Caps can be sealed with silicone
- Fit Bottom Outlet to channel

and seal with silicone • Join 90mm PVC stormwater pipe to End or Bottom Outlet with PVC plumbers glue



4. Pour Concrete

- Rain Mate® installations must be set in concrete
- Cover grate with tape to protect from concrete splash
- Pour concrete

and finish top surface 2mm above level of the grate • Allow full cure before removing grates or vehicle use - 3 days • Grates can be removed by inserting screw driver into slot and twisting gently to lift grate • For further details on installation, please visit www.reln.com.au