

# **INSTRUCTION GUIDE**

# **Residential Meteor Lights**

Model No. SLDML-36W, SLDML-36WW, SLDML-36RGB

### **PACKAGE CONTENTS**

- 1. 10 x Meteor Lights per kit
- 2. 1 x 2w Separate E.R.E Solar Panel
- 3. 1 x Panel Mount Spike
- 4. 5m Cable from Solar Panel





## **IMPORTANT NOTES**

- Please ensure you place your solar panel in a location where it can achieve a minimum of 6HRS DIRECT SUNLIGHT
- Be aware that on overcast/cloudy days, the solar panel will still charge. However, not as efficiently as a sunny day, so the battery may not reach full capacity. Therefore, your light may turn off earlier than specified
- It's best not to install the solar panel underneath a street light, porch light etc. because this may stop the automatic day-night sensor triggering and result in your lights not turning on

### **FEATURES**

- 1. 10 Meteors per kit
- 2. "Plug and Play" Installation
- 3. Built in Photo Electric Cell
- 4. 8-10 hours Operation every day
- 5. DIY and Easy to Install
- 6. Cable Colour Transparent
- 7. Spike or Surface Mounting Option for Remote Solar Panel
- 8. Colour White OR Warm White OR Red, Green & Blue

# TROUBLE SHOOTING

Phenomenon	Cause	Inspection Method	Solution
Light won't turn on	Switch hasn't been turned on	Determine what position the switch is in	Turn the switch on
	Battery has run flat	Period of rainy or cloudy weather or installation site doesn't provide enough direct sunlight	Charge the light in direct sunlight for 1-2 days then check again
The light only stays on for a short amount of time	Low Battery	1. Bad installation site for the solar panel 2. Dust or leaves are covering the panel 3. Long period of overcast weather	1. Charge the battery in direct sunlight for 1-2 days with the switch off, then check again 2. Clean the solar panel
	Battery Failure	Access the light and     Replace battery     Battery has     matured	Contact SLD Customer Service to buy new batteries

#### **INSTALLATION METHOD**

- 1. Remove contents from packaging
- Press button on the back of solar panel "ON" (Please note; your light is packaged & transported with the power button in the "OFF" position)
- 3. Decide where to install your lights & panel

**Meteor Lights** - Locate where to situate your lights and install them as you wish making sure that the length of cable will reach to the solar panel and each light

**Panel** - Mount panel within the cable length either via the supplied ground mount spike or using the surface mount option on a nearby roof or wall. Ensure it will receive maximum direct sunlight during the day. Attach the cable from panel to lights

Customer Service Number: 1300 135 911 www.solarlightingdirect.com.au