

INSTRUCTION GUIDE

Industrial Park Light

Model No.SLDPKL18W-ZAP


INSTALLATION METHOD

- 1. Remove contents from packaging
- Place park light head upside down and gently twist the UV light into the thread in the middle of the light fitting
- 3. Connect Bug Zapper by attaching the cable from the light head to the zapper
- 4. Using the 4 x supplied screws, fasten the bug zapper to the light fitting using an Alan key
- Before continuing, we recommend you place your light in a location where it will receive maximum direct sunlight (with the light in the "OFF" position) for 2 days before installation
- Turn the light "ON" and adjust mode to your preference (Please refer to "UNDERSTANDING YOUR REMOTE" & "UNDERSTANDING YOUR LIGHT" for these steps)
- 7. Install on your chosen post

UNDERSTANDING YOUR REMOTE



UNDERSTANDING YOUR LIGHT



- (1) ON/OFF Switch
- (3) UV Light
- (2) LED Lights
- (4) Rain Sensor

IMPORTANT NOTES

- Please ensure you place your solar panel in a location where it can achieve a minimum of 6HRS DIRECT SUNLIGHT
- Be aware that on overcast/cloudy days, the solar panel will still charge. However, not as efficiently as a sunny day, so the battery may not reach full capacity.
 Therefore, your light may turn off earlier than specified.
- It's best not to install the fitting underneath a street light, porch light etc. because this may stop the automatic day-night sensor triggering and result in your lights not turning on

TROUBLE SHOOTING

Phenomenon	Cause	Inspection Method	Solution
Light won't turn on	Switch hasn't been turned on	Determine what position the switch is in	Turn the switch on
	Battery has run flat	Period of rainy or cloudy weather or installation site doesn't provide enough direct sunlight	Charge the light in direct sunlight for 1-2 days then check again
The light only stays on for a short amount of time	Low Battery	1. Bad installation site for the solar panel 2. Dust or leaves are covering the panel 3. Long period of overcast weather	1. Charge the battery in direct sunlight for 1-2 days with the switch off, then check again 2. Clean the solar panel
	Battery Failure	Access the light and & replace battery Battery has matured	Contact SLD Customer Service to buy new batteries