



INSTRUCTION GUIDE

Residential Double Head Post Light

Model No. SLDPL0007B, SLDPL0008B, SLDPL0009B, SLDPL0012B, SLDPL0018B



INSTALLATION METHOD

1. Remove contents from packaging

NOTE: Before continuing, we recommend you place your light in a location that will receive maximum direct sunlight (with the switch in the "OFF" position) for 2 days before installation

2. Make sure to switch your light heads "ON" before installation (**FIGURE 3**)
3. Using the supplied Nuts & Bolts, fix the post base mount in your desired location
4. To connect the 4 part post, starting with the bigger posts on the bottom, to the smaller posts on top. Simply connect the posts by twisting clock-wise to tighten (**FIGURE 1**)
5. To connect light heads on to the decorative post top, twist the light heads into each adapter (**FIGURE 2**)

IMPORTANT NOTES

- Please ensure you place your solar panel in a location where it can achieve a minimum of 6HRS DIRECT SUNLIGHT
- Be aware that on overcast/cloudy days, the solar panel will still charge. However, not as efficiently as a sunny day, so the battery may not reach full capacity. Therefore, your light may turn off earlier than specified
- It's best not to install the fitting underneath a street light, porch light etc. because this may stop the automatic day-night sensor triggering and result in your lights not turning on

TROUBLE SHOOTING

Phenomenon	Cause	Inspection Method	Solution
Light won't turn on	Switch hasn't been turned on	Determine what position the switch is in	Turn the switch on
	Battery has run flat	Period of rainy or cloudy weather or installation site doesn't provide enough direct sunlight	Charge the light in direct sunlight for 1-2 days then check again
The light only stays on for a short amount of time	Low Battery	1. Bad installation site for the solar panel 2. Dust or leaves are covering the panel 3. Long period of overcast weather	1. Charge the battery in direct sunlight for 1-2 days with the switch off, then check again 2. Clean the solar panel
		Battery Failure	1. Access the light and replace battery 2. Battery has matured




FIGURE 1



FIGURE 2




FIGURE 3