


P45514ML1W

Larder

Instruction Manual

This product was supplied by Shomar Ltd Dublin. We can be contacted on Ph 01- 4505327 or by visiting our website www.shomar.ie

General Description of Refrigerator



- | | |
|-----------------------|------------------------|
| 1. Upper Cover | 2. Thermostat |
| 3. Refrigerator Shelf | 4. Salad Crisper Cover |
| 5. Salad Crisper | 6. Adjustable Foot |
| 7. Egg Tray | 8. Pocket Rack |
| 9. Bottle Rack | |

Transportation and Handling

When Transporting, Never place the appliance upside down. When the

appliance is out of carton never lift or move by using the door.

Installation

1. In order to Prevent vibration and noise install the refrigerator on flat, firm surface.
2. Choose a well-ventilated place. A space of no less than 10cm must be left around the refrigerator.
3. Choose a location where there is no heat source. Keep the refrigerator away from direct sunlight and oven etc..
4. Choose a dry and well-ventilated place where there is no corrosive air.

Testing

1. Clean the parts of the refrigerator with lukewarm water containing a small amount of washing up liquid, then wipe dry

Notes: Electric parts of the refrigerator can only be wiped by dry cloth.

2. Turn the thermostat knob to the "3" position, turn on electricity. The compressor and the light inside the refrigerator begin to work.
3. Close the door and leave for 30 minutes, if the temperature on back wall decreased obviously, it shows that the refrigerator system is working

Temperature Control

1. The temperature in the refrigerator compartment is controlled by the temperature controller installed on the side wall of the refrigerator compartment.
2. Turn the thermostat knob to right or left, you can regulate the temperature inside the refrigerator.

Storage of Food

1. How to Use the Refrigerator Compartment

- *Cooked food can be put into the refrigerator to keep fresh after the temperature decreases to room temperature
- *To prevent odors food should be wrapped in aluminum foil, placed in suitable polythene bags and stored in proper airtight containers.

2. Placement of Food

- *Sufficient space should be left between foods, Over filling will cause the appliance to fail
- *Food to be stored should be wrapped with clean plastic film.

Notes:

- *The appliance should not be used in open air and shall not be exposed to rain.
- *Don't store methanol, petrol etc.
- *Don't store heavy Items on top of refrigerator.
- *Do connect your refrigerator to an independent electrical socket and use a safe ground wire. The voltage should be limited within the ranges from 220V to 240V, or the main motor will be damaged.
- *In the event of a power cut turn off the appliance at the mains, Turn on the power 5 minutes after the power return's, Otherwise, the compressor may be damaged.
- *In order to save electricity consumption, keep air circulation during operation by not over filling.
- *Sure to keep electrical wire away from compressor and condenser, or its insulation function will be spoiled by high temperature.
- *To save the energy, you should reduce the frequency and duration of the opening of the door.
- *It is not recommended to use any extension cords.
- *Warning-Do not damage the refrigerant circuit.

The appliance must be positioned so that the plug is accessible.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

General Instructions for Care and Maintenance

The refrigerator should be cleaned every other month, before cleaning, the electric plug must be removed from the power supply.

Wipe the inside and outside of the refrigerator with a wet soft cloth.

If it's too dirty, clean with a soft cloth soaked with neutral detergent and clean water, remove the moisture with dry cloth.

If you are going away on holiday or for any other reason, wish to leave the refrigerator idle for any period of time, proceed as follows:

- *Disconnect the refrigerator from the electric power supply by removing the plug from the wall socket.
- *Remove all food.

*Clean and dry the inside as instructed in the direction given above for cleaning.

*Leave the doors open to prevent any unpleasant smells from building up while the refrigerator is not used.

Cleaning:

*When cleaning the refrigerator the electric plug must be removed from the power supply.

*Use water and a non-abrasive detergent.

*Clean with a soft cloth soaked in this solution and remove moisture with a dry cloth.

*Remember to clear the defrost drain situated at the back just above the glass cover.

Replacing the light bulb

Should the light fail, switch off at the socket outlet and pull out the mains plug. Then ensure the bulb is screwed securely in the bulb holder. Replace the plug and switch on. If the light still fails, obtain a replacement E14 screw-cap type 15 Watt (Max) bulb from your local electrical store and then fit it. Carefully dispose of the burnt-out light bulb immediately.

Symptom:

Appliance will not work at all.

Cause:

The power supply plug is not inserted in the wall socket or the plug and the outlet is loose.

Due to some anomaly in the household electric supply circuit, no power is reaching the refrigerator supply socket. This can be checked by plugging in a light or any other electric appliance into the suspect socket.

The voltage is too low.

Symptom:

Noisy running.

Cause:

The appliance has not been properly leveled.

The refrigerator contact with the wall.

The accessories in the refrigerator are placed wrong position.

Symptom:

Appliance does not cool sufficiently.

Cause:

Door has been opened too often, or it has been left open for a while.

The refrigerator is too near to the wall.

Too much food in the refrigerator.

Have not regulate the temperature correctly.

Symptom:

Smell inside the appliance.

Cause:

Some of the food is not properly wrapped or covered.


The inside of the refrigerator needs cleaning.

If your refrigerator shows other symptoms from those described above, or if you have check all items listed as the causes and the symptom still exist, then call the service department.

The Following Are not Breakdowns

- 1.Refrigerant running in pipes gives forth a gentle sound of water running in pipes.
- 2.In a moist season, the outer surface of refrigerator may be covered with moisture which should be simply wiped away.
- 3.The compressor and the rear condenser may be heated to the extent that scalding your hand in summer during refrigerator operation.

Diagram of Circuit Principles



Due to product's changing and improving, the exact product for the consumer may not correspond with some details in the instruction.

Remarks

This appliance is intended for domestic use only

For Information regarding the warranty period for use in

– staff kitchen area's, office's, Hotel's , Restaurants , B&B type environments catering and similar non-retail applications please contact our Service Dept on 01 –4505327 /337