

**BLACK CAP :
TIRE REAMER**

To ream the puncture area for easy repair.

**SILVER CAP :
TIRE INSERTION TOOL**

To plug the tire strip into the puncture area.

**INSTRUCTIONS**

- 1 Locate source of puncture and remove debris from the source of the puncture.
- 2 Insert tire reamer into the source of the puncture and rotate the tire reamer to ream the puncture area to ensure tire strips can be applied.
- 3 Select type of tire strip depending on the tire puncture size. Use black tire strip plug for larger puncture and brown bacon tire strip plug for smaller puncture.
- 4 Lace a tire strip plug into the eyelet of tire insertion tool. The middle of the tire strip plug should be in the eyelet.
- 5 Push tire strip plug into the hole. Twist the tire strip plug to make bunch it up inside the tire, ensuring the ends of the tire strip plug remains on the outside of tire.
- 6 With the tool and plug still in the tire, slowly remove the tool and make sure the tire strip plug remains in the tire. (Carefully hold onto tire strip plug if necessary)
- 7 Re-inflate the tire to your desired pressure using a bike pump or CO2 inflator. Once the tire is inflated with no signs of leaking, trim the excess of the strip plug off the tire surface.

Please note this is a temporary fix to get you home and not stranded on the trail. Please do a careful inspection of the tire after getting home to do a proper patching of the tire or replace with new tire.

THANK YOU FOR YOUR PURCHASE.

We are committed to your satisfaction.
If you are not happy with your purchase or need help,
please contact us at info@marquecycling.com
and we can make it right for you.

FOLLOW US!

To receive awesome deals and information on
all the latest products from MARQUE Cycling,
sign up for our newsletter at marquecycling.com,
or follow us at:



MARQUECYCLING



MARQUECYCLING



MARQUECYCLING