





## Jeep TJ Back Half Kit Part Number MB3008



This back half kit allows you to replace the rear section of the stock frame completely to make room for coil overs and to move the rear axle further back. Remove all factory suspension components, fuel tank, rear axle and other parts from the rear frame section.

The first step is to cut the frame where the upward curve begins.



This will allow us to slide on the first part of the Motobilt Jeep TJ back half kit. The new frame rail sections come welded and ready to slide over the frame rails.



The next step was to mock up the long straight frame rail sections and rear bumper.



On the inside of the long straight frame rails there is a body mount tab with hole. This lines up with the factory body mount in the middle of the cross member.





This TJ has a 1.5" body lift so we only had to cut the tub a small amount. You can see where we notched the body just below the tail gate. This kit will work without a body lift but you will need to cut more in this area.



You can clearly see how the frame has moved further up and no longer dips down in the back. This means when we move the rear axle back we will have the necessary room, while allowing us to keep the Jeeps height as low as possible.

Once the body mount is bolted in you can square up the frame with the bumper and make sure you are happy with the placement. Tack welded all of the sections together. You can now weld the back half kit while its underneath the Jeep or you can choose to remove it and weld it separately.



Be sure to test fit the frame rails during the process to ensure nothing moves. Remember it's better to check and be sure than to rush things. You will need to weld the reinforcement end caps that connect the frame rails to the bumper.



Next reinstall the back half onto the Jeep and weld the new frame rails to the factory rails.

