

AC Voltage Tansmitter

Sub-plate mount, terminal output.

Detect AC voltage, high insulation between primary and secondary circuits.





Product features


- ·Light weight
- •Low power consumption
- Good linearity
- · Easy to use
- Fast response time
- Good anti-interference ability

Product application

- Railway
- Metallurgical
- ·Welding machine
- Robot
- Motor
- •Inverter power supply
- Variable frequency governor
- Uninterrupted power supply and communication power supply

Installation diagram

High side wiring terminal proposal seal after processing





 $Electrical\ parameters:\ (\ The\ following\ parameters\ are\ typical\ values\ and\ actual\ values\ will\ be\ subject\ to\ product\ testing)$

Remarks

Rated input	500V	800V	1000V	1500V	2000V	Standard input
Input measurement range	600V	960V	1200V	1800V	2400V	Default is 1.2 times tof he input rating
Rated output	$0\!-\!20\text{mA}/4\!-\!20\text{mA}/0\!-\!5\text{V}/1\!-\!5\text{V}/0\!-\!10\text{V}$					Output can choose one of five 0-10V output choose +24V power supply
Accuracy	1%					
Linearity	0.5%					
Supply voltage (\pm 5%)	+12V / +24V				Choose one, supply voltage range ±5%	
Current consumption	≤35mA				Reference will be subject to the measured	
Load impedance	Current 250Ω(7	Current type output: $250\Omega(\text{Typification})$			e output:	
Zero offset voltage	Current ±0.08m	type outpu A	it: \ \ \ \ =	Voltage type ±15mV	e output:	TA=25℃
Response time	≤350mS					Reference will be subject to the measured
Weight	600g				Reference will be subject to the measured	
Operating temperature	-10 ~ +70 °C					
Storage temperature	-25 \sim $+70$ $^{\circ}$ C					
Band width	$25 \mathrm{Hz}^{\sim} 1 \mathrm{KHz}$					
Delectric strength	6KV 50Hz 1min					

Instruction for use:

- 1. Correct wiring as indicated
- 2. Full scale measurement, response time and following the speed for the best
- 3. Faulty wiring can lead to product damage and output uncertainty

Safe operation:


- *Please read this specification carefully before use.
- *When you need to move the product, please be sure to disconnect the power and all the connected cables.
- *If found shell, devices attached to the fixed parts, wire, or have any damaged, please immediately deal with hidden dangers.
- *If there is any doubt about the safe operation of the equipment, the equipment and the corresponding accessories should be closed immediately, and the fastest time for troubleshooting.


Proclamations:

As our products are constantly being improved and updated, we reserve the right to modify the content of this specification at any time without prior notice.




Dimensions(in mm±0.5):





Wiring diagram:



Terminal definition:

- 1: +V
- 2: GND
- 3: Output
- 4: GND
- -HT (Measured voltage)
- +HT (Measured voltage)
- ****** ①The auxiliary power supply with ripple small (≤20mV) is selected
 - 2 Switch on auxiliary power
- ③Auxiliary power is connected to the transmitter
- **4** Transmitter detects the primary current
- ⑤Both GND internals are not isolated