



**NORTHERN
BREWER**

INSTRUCTIONS
DELUXE STARTER KIT

**BAVARIAN
HEFEWEIZEN.**

BREW DAY

EQUIPMENT NEEDED FROM KIT

- Beer recipe kit
- Cleanser
- Bottling bucket
- Spigot
- Lab thermometer
- Funnel
- 6 gallon glass carboy (the larger of the two carboys)
- Carboy bung
- Airlock
- Blow-off hose
- LCD thermometer

ADDITIONAL EQUIPMENT NEEDED

- Pot that holds at least 4 gallons (with lid)
- Timer
- Large bag of ice (18-20 lbs)
- Scissors
- Tablespoon
- Towel
- Dishrack
- Tape measure (optional)
- Kitchen spoon

GETTING READY

- Place the jug of liquid malt extract in warm water. This will help when pouring the malt into the boil later.
- Install the spigot on the bottling bucket. If your spigot has two rubber gaskets, ensure you have one gasket on each side of the bucket wall. If it only has one, make sure it is installed on the outside of the bucket. Test for leaks by filling the bucket with water until the spigot is fully submerged.
- With a tape measure, measure 15" up the side of the larger carboy. Mark this spot with a permanent marker or piece of tape. This line indicates approximately 5 gallons.
- Prepare your fermentation area. Ideally, this is a location out of direct light with a steady temperature around 68°F.

HEAT WATER

If your water is good enough to drink, it is good enough for brewing. Fill the clean pot with 2.5 gallons of cool water. Place on stove, uncovered, over MEDIUM heat.

BOIL

Bring the water to a boil and remove from heat. Stir in 6 lbs Wheat malt syrup and 1 lb Wheat DME with a kitchen spoon until dissolved. You now have wort, the brewer's term for unfermented beer. Return the pot to stove over HIGH heat and resume boiling. Actively monitor foam! When foam rises, reduce or remove from heat until foam subsides. Adjust heat as necessary to maintain a slow, rolling boil. Set a timer for 60 minutes and add 1 oz Tettnang hops. After the 60 minutes has passed and the timer goes off, turn off heat and cover the pot.

COOLING

Place covered pot in sink. Fill sink with cold water and ice up to the height of the wort in the pot. Set timer for 30 minutes. While the wort cools, move to the next step.

DECONTAMINATE

Fill bottling bucket with 1 gallon of hot water. Mix in 1 tbsp. of cleanser and stir until dissolved. Pour some cleanser solution into the 6 gallon carboy (fermentor). Carefully swirl carboy, ensuring contact with all inside surfaces for 2-3 minutes. Pour cleanser solution back into bottling bucket. There is no need to rinse carboy of solution.

BREW DAY CONTINUED

DECONTAMINATE CONTINUED

Soak funnel, airlock, carboy bung, scissors and yeast pack in cleanser solution, again ensuring contact with all surfaces.

TRANSFER

Add 1 gallon of cool water to the fermentor. When the timer goes off, remove the lid from the pot and pour the wort into the fermentor using the funnel. Top off with cool, drinkable water until the wort level rises up to the 5 gallon mark on the fermentor.

PITCH YEAST

Cut open the yeast pack with clean scissors. Sprinkle the contents on the surface of the wort. Firmly insert the carboy bung into the neck of the carboy. Fill the airlock with cleanser solution to the fill line and insert airlock into the hole of the carboy bung.

CLEAN UP

Using your cleansing solution, wash all used equipment and allow to dry fully before storing. Do not use abrasive brushes that may scratch your equipment. Discard cleansing solution.

FERMENT

Move the fermentor to your prepared fermentation area. Within 24-48 hours, bubbles may start forming in the airlock or a thick foam may rise from the surface of the wort. This is a normal part of the fermentation process. Allow the process 14 days to complete, then move on to bottling day.

BOTTLING DAY

EQUIPMENT NEEDED FROM KIT

- Bottling bucket
- Spigot
- Siphon & tubing (long section)
- Bottle brush
- Bottle filler & tubing (short section)
- Bottle capper, caps, & labels
- Priming sugar (from recipe kit)
- Cleanser
- Carboy dryer & carboy brush

ADDITIONAL EQUIPMENT NEEDED

- 48 clean, empty, pry-off beer bottles
- Tablespoon
- Dish Rack
- Small saucepan with lid
- Timer
- Towel
- Storage box for filled bottles

GETTING READY

- About a half hour before starting the process, carefully move your fermentor to an elevated position, like the edge of a counter or tabletop.
- Re-test the bottling bucket for leaks by filling the bucket with water until the spigot is fully submerged.
- Soak one end of the long siphon tubing in HOT water for 30 seconds to soften. Push softened end of tubing over the cane portion of the auto-siphon about $\frac{1}{2}$ inch.

DECONTAMINATE

Fill the bottling bucket with 1 gallon of hot water. Mix in 1 tbsp. of cleanser until dissolved. Soak bottles in cleanser solution, ensuring contact with all surfaces. Place bottles upside down in dish rack to dry. Soak caps and bottle filler in the cleanser solution, again ensuring contact with all surfaces (including the inside surface of the bottling bucket) for 2-3 minutes. Place the tip of the auto-siphon and the disconnected end of the auto-siphon tubing in the cleanser solution. Pump the cane a few times to force cleanser through the inside of the siphon and tubing. Rinse the outside of the siphon and tubing with cleanser solution. Move all items from bottling bucket to a cleansed surface. Empty solution into stoppered sink for final clean up.

BOTTLING DAY CONTINUED

PRIMING SOLUTION

In the small saucepan, mix the entire pack of priming sugar in 16 ounces of water. Turn the stove to MEDIUM and heat the solution to a boil. Once the solution is boiling, set the timer for 10 minutes. When the timer goes off, turn off the stove, place the lid on the pan, and set the timer for 10 more minutes to give the solution time to cool. When the timer goes off, pour the solution into the bottling bucket.

TRANSFER

Place the bottling bucket on the floor near the fermentor. Place the auto-siphon in the fermentor and the open end of the tubing in the priming solution at the bottom of the bottling bucket. Gently pump the auto-siphon 2-3 times until the beer flows through the top of the siphon. Let gravity fill the bottling bucket, taking care not to splash.

BOTTLING

Gently move the full bottling bucket to an elevated position, such as the edge of a counter or tabletop. Attach one end of the short tubing to the bottle filler and the other to the spigot. Open the spigot on the bottling bucket and press the tip of the bottle filler to the inside bottom of the first bottle. Fill the bottle to the top, which will leave about 1 inch of headspace in the neck of the bottle once you remove the filler. Place a cap on top of the bottle and set aside. Repeat the bottling step until there is no beer left in the bottling bucket.

CAPPING

Center the bottle capper over the cap on a bottle. Press straight down firmly on the capper's handles to seal the cap onto the bottle. Wipe the bottle with a dry towel, apply your label and place the bottle in the storage box. Repeat the capping steps until all bottles have been sealed.

CLEAN UP

Use cleansing solution to wash all used equipment and allow to fully dry before storing in a dry location until the next brew day. The included brush is great for getting rid of stubborn residue in the carboy, and an inverted carboy fits perfectly in the carboy dryer to store until the moisture is gone.

CONDITIONING

Store the bottles in a dark area at 65-75°F for at least 2 weeks to carbonate. After 2 weeks, the bottles can be stored in the fridge.

SHARE, ENJOY!

When chilled, your beer is ready to serve! Pour gently into a clean glass, taking care to leave the layer of sediment at the bottom of the bottle behind. Cheers!

CONTACT US

BEER KIT GUARANTEE

We're so confident in the quality of our beer kits, we'll replace any kit, anytime, no questions asked.

**WE'VE GOT
YOUR BATCH.▲**

BREWING SUPPORT

By Email: Brewmaster@NorthernBrewer.com

Homebrew Help: Learn.NorthernBrewer.com

By Text Message: 651-273-9869

By Chat: Online from 9AM to 6PM CT

By Telephone: 1-800-681-2739

NORTHERNBREWER.COM

