

## **Item Number**

RAM-VB-194 & RAM-VB-194-SW1

# RAM Seat Bases

RAM Mounting Systems

## **Vehicle base for:**

FORD TRANSIT FULL SIZE VAN (2014-NEWER)

## **SPECIFICATIONS**

### **Placement**

Between seat track and seat frame box.  
Inside front corner of passenger side seat.

### **Drilling Required**

No. Utilizes existing vehicle mounting points  
and hardware.

### **Seat Configuration**

Bucket

### **Construction/Finish**

Steel/Black Powdercoat

### **Dimensions**

4.5" L x 7.5" W x 2" H

### **Pole or Pedestal**

Sold separately

### **Weight**

2.25 lbs.



Complete Vehicle Mount  
RAM-VB-194-SW1



Vehicle Base  
RAM-VB-194

## **Features**

Installs in minutes with no drilling required.

## **Misc.**

Rugged lifetime warranty construction  
Additional holes may be drilled in base to create additional mounting  
options without voiding the warranty.

### **RAM Mounting Systems**

8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
[www.rammount.com](http://www.rammount.com)  
[support@rammount.com](mailto:support@rammount.com)



RMR-INS-VB-194

**Item Number** \_\_\_\_\_

RAM-VB-194 & RAM-VB-194-SW1


# RAM Seat Bases

RAM Mounting Systems

**Vehicle base for:**  
**FORD TRANSIT FULL SIZE VAN (2014-NEWER)**

## Installation instructions for bucket seats.

1. Move the passenger side seat to it's most forward position.
2. Using a T-40 Torx bit, loosen but do not remove the two rear seat track bolts.
3. Move the passenger side seat to it's most rearward position.
4. Using a T-40 torx bit, remove the two front seat track bolts on the passenger side seat.
5. Using a T-45, remove the bolt at the inside front of the seat frame box.
6. Gently tilt the seat back creating a gap between the seat frame box and seat track.
7. Place the No-Drill base at the front inside corner of the seat frame box.
8. Place the spacer washer over the mounting hole located on the door side where you removed the bolt.
9. Lower the seat back down and re-install / re-tighten all the seat mounting bolts. This includes the bolt at the inside front of the seat frame box that requires the use of the T-45 torx bit.



**RAM Mounting Systems**  
8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
[www.rammount.com](http://www.rammount.com)  
[support@rammount.com](mailto:support@rammount.com)



RMR-INS-VB-194