

Item Number

RAM-VB-195 & RAM-VB-195-SW1

RAM No-Drill™ Seat Bases

RAM Mounting Systems

**Vehicle base for the
FORD F-150 (2015-NEWER)****SPECIFICATIONS****Placement**

Passenger side, in front, where seat frame meets floor board.

Drilling Required

None - uses existing seat bolts

Seat Configuration

Bucket or 40/20/40 split bench

Pole or Pedestal

Ordered Separately

Construction/Finish

Steel/Black Powdercoat

Dimensions


A = 14.875", B = 7", C = 2.00",
Hole Center = 13.625"

Features

Installs in minutes with no drilling required. Placement is over the top of the seat frame legs at floor board level. Rock solid construction. Lifetime warranty. Though not necessary for all applications, kit comes with additional stabilizer foot to help support heavier devices.



Complete Vehicle Mount
RAM-VB-195-SW1



Vehicle Base
RAM-VB-195

RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-195

Item Number _____

RAM-VB-195 & RAM-VB-195-SW1

RAM No-Drill™ Seat Bases

RAM Mounting Systems

**Vehicle base for the
FORD F-150 (2015-NEWER)**

INSTALLATION INSTRUCTIONS

Please read through the installation instructions entirely before beginning the installation of this product.

Depending on your make and model, there may be pieces of plastic trim that cover the lower front of the seat frame legs. This will need to be removed and stored. In some Ford models, under the plastic trim cover is a small Allen head screw. Remove this to allow the plastic trim to accommodate the no drill base.

1. Move the passenger side seat to its rearmost position.
2. Using the appropriate socket, loosen and remove the two bolts holding the seat frame legs to the floor board.
3. Gently lift the front of the seat upward to create a 1/4 inch gap under the seat frame legs.
4. Slide the No-Drill™ base under the seat frame legs with the pedestal platform near the center of the vehicle and align the holes of the seat legs, no drill base, and threaded holes in the floor pan.
5. Re-install the two seat frame bolts. Start the thread by hand and then fully tighten with the socket wrench.
6. Though not necessary for all applications, this base come with a stabilizer foot. Use this in the place of one of the carriage bolts that secure the lower female pole to the no drill base. This foot should be adjusted so that it touches off on the floor pan and supports the overhang of the base.

RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-195