RACKLESS

Awning Mount System

Important:

Installation should only be done by a qualified person and it is the responsibility of said person to ensure correct fitment.


Please read all procedures and precautions before installing and using the Rackless Awning Mount System. If you have any questions please contact us via email on the back of this installation manual.

Warning!

Please follow these steps when drilling the roof to avoid damage to the side curtain airbag mechanism. Failure to follow these steps will result in vehicle damage. It is recommended the vehicle roof head lining should be removed to ensure nothing is below the drilled position.


Information:

For individual vehicle specifications & terms and conditions refer to page 4.




Warning!

 ${\it Max}$ Drill Depth is ${\it 5mm}$



Drill approximately halfway and then use a vacuum to remove swarf from roof channel. Continue drilling the hole, repeat operation for remaining holes.



Care Instructions:

Clean vehicle roof before fitting Rackless roof mounts.

Tools Required:


- Vacuum cleaner
- 5mm drill bit with depth stop
- Marking pen
- Rivet gun with head to fit inside 12mm counter sunk hole
- Cordless or power drill
- Hammer and centre punch
- Rust stop paint and brush
- T30 torx security socket bit and torque driver
- · Silicon and caulking gun

Fitment Instructions:

 Before installation check bracket and mount application is compatible with your vehicle.

Note: For vehicles with factory roof rails or gutter mount brackets, please refer to manufacturers instructions for removal and installation.

- Place the mount on top of the rubber in the channel and measure from the edge of the windscreen rubber to the first rivet hole. The use of masking tape will help maintain this measurement while marking where to cut the rubber trim.
- 3. Wrap tape around a flat blade screw driver to prevent paint scratching then gently lever the rubber trim from the roof gutter then using fingers carefully pull upwards. Small plastic clips are attached to the roof underneath each end of the strip.




4. Cut the rubber roof trim with tin snips at places marked in previous step and put back in the vehicle roof channel at the front, middle and rear of the tracks, the front piece needs to be measured so the end of the trim sits under the windscreen rubber.

- Measuring tape
- Tin snips
- Tape
- Flat blade screwdriver

Full Kit Contents:

- 2x Rackless bracket assemblies
- 4x T30 Stainless security bolts
- 4x Stainless washers
- 2x Stainless roof mounts
- 2x Stainless plates
- 6x Stainless pop-rivets




Note if applicable: The glue around the roof rack nutsert holes will need to be removed so the mount can sit flat in the channel.

Note: The measurement and cutting of the rubber should be cut at the end of each mount and the top plate will cover the gap. A small amount of silicon can be used to help hold in place.

Note: Some makes & models have double sided tape applied so be sure not to kink the rubber when removing.

 Place the mount in the channel, mark the holes 1 using a marking pen, remove the mount. Do the same for the opposite side mount. See measurements guide on page 4 of these instructions.

Note: Purpose of extra holes on one roof mount is for fitment of optional LED light bar and should be placed facing the front of the vehicle.



Accurately centre punch all holes before drilling.




 Marked out holes can now be drilled using a 5mm drill bit with a drill stop. Set up the drill stop ensuring you don't drill through the roof lining.




8. Use a vacuum to remove swarf from the roof channel.



 Apply anti rust paint to the inside and surrounds of all holes, allow for time to dry before applying silicon around each hole and along the mount length.




10. Accurately place the mount over the drilled holes in the roof channel using the rivets to position.




11. Using rivet gun, rivet the mount into place, make sure all rivets are seated firmly onto the base of the mount.


Note: Once pop rivets are fitted counter bore can be filled with silicon to prevent from holding water.



12. Fit top plate with one bolt (M6x10mm) end 3, this bolt will hold the top plate when the Rackless Light bar mount or Awning mount system is not installed. One bolt should be fitted in 1 when neither are installed.



13. Light Bar bracket to be fitted to the roof mount front 2 holes with 4x M6 bolts and washers using an Anti-theft torx bit. Tighten bolts evenly to a torque of 6Nm.



Note: Brackets are slotted to allow for different width cars, all bolts should be tightened in intervals to allow for the brackets to be even.

14. Install light bar as per manufactures instructions. Light bar recommended is 42 inches long.

Maintenance Recommendations:

It is essential that all bolts and connections be checked after driving a short distance when you first install your awning mounts.

All bolt connections should be checked again at regular intervals (more often on rough road conditions). Ensure bolts are to specified torque as per above installation instructions.

Sensitivity to cross winds and behaviour in curves:

The handling characteristics of the vehicle changes with the wind drag of overhead accessories, for safety reasons we recommend you exercise extreme care when driving.

Please remove Mounts when putting vehicle through an automatic car wash.

Note to Dealers and Fitters:

It is your responsibility to ensure instructions are given to the end user or client.

Additional Note:

No responsibility or liability will be held against supplier for incorrect fitment of product resulting in component or vehicular failure or damage.

It is the responsibility of the vehicle owner to check local laws for roof mounted lighting and we recommend for off road use only.

By purchasing this product, you agree to all of these conditions.

Vehicle Make & Model	Front Mount 1 st hole from Windscreen
Toyota Hilux N70/N80	240mm
Isuzu D-Max/Mazda BT50 2020+	280mm
Isuzu MUX (LS-M/LS-U)	250mm
Holden Colorado RG	280mm
Ford Ranger PX	227mm
Mazda BT50 2011-2020	227mm
Mitsubishi Triton	245mm

Chalming Creations will warrant the original purchaser against manufacturing faults and defects in material for a period of 12 months from original purchase date.

- To obtain warranty, Chalming Creations must be provided with proof of purchase and photographic proof of fault. This warranty does not cover the removal or re-installation of the product.
- To obtain warranty, Chalming Creations must be provided with proof of fitment by a qualified person.
- Chalming Creations reserves the right, at its option, to repair, replace or refund the purchase price of a faulty or defective product or its components if returned to the place of purchase during the warranty period.
- When returning a product for warranty assessment it must be accompanied with the customer's name, address, contact phone number, a clear description of the fault and a copy of the original sales receipt detailing the date of purchase.
- For bent products being returned, they will be tested to hold 30kg each. If the desired weight is held they will not be classed as defective and classed as improper use or acts of nature. A typical awning weighs approximately 13kg and will not bend the product if set up and fitted correctly. Please ensure your awning is set up so it does not collect water and secured down with guy ropes as per manufacturers instructions.
- This warranty does not apply to damage due to accident, misuse, abuse, misapplication, collision, modification, improper installation or improper maintenance.

For change of mind purchases, the product must be returned in full within 30 days of the shipment date. A partial refund will be issued (minus any merchant, postage and packaging costs) with return postage being the purchasers responsibility.